

# BODY

## TABLE OF CONTENTS

	page		page
PAINT .....	1	SEATS .....	15
STATIONARY GLASS .....	4	BODY COMPONENTS .....	24
POWER SUNROOF .....	8		

# PAINT

## TABLE OF CONTENTS

	page		page
<b>DESCRIPTION AND OPERATION</b>		PAINTED SURFACE TOUCH-UP .....	2
PAINT CODE .....	1	<b>SPECIFICATIONS</b>	
BASE COAT/CLEAR COAT FINISH .....	1	AFTER MARKET PAINT REPAIR PRODUCTS .....	3
FINESSE SANDING, BUFFING, AND POLISHING .....	1		

## DESCRIPTION AND OPERATION

### PAINT CODE

#### DESCRIPTION

Exterior vehicle body colors are identified on the Body Code plate. The plate is located on the in the engine compartment and attached to the top of the right frame rail. Refer to the Introduction section at the front of this manual for body code plate description. The paint code is also identified on the Vehicle Safety Certification Label which is located on the drivers door shut face. The first digit of the paint code listed on the vehicle indicates the sequence of application, i.e.: P = primary coat, Q = secondary coat. The codes listed in the Aftermarket Paint Repair Products chart are used for manufacturing purposes. The first digit may vary from the Body Code Plate. The color names provided in the Aftermarket Paint Repair Products chart are the color names used on most repair product containers.

### BASE COAT/CLEAR COAT FINISH

#### DESCRIPTION

The original equipment finish is a multi-step process that involves cleaning, electrodeposition (e-coat), base

coat, and clear coat steps. Additionally, selected areas of the vehicle may be coated with an anti-chip finish.

#### OPERATION

On most vehicles a two-part paint application (base coat/clear coat) is used. Color paint that is applied to primer is called base coat. The clear coat protects the base coat from ultraviolet light and provides a durable high-gloss finish.

**CAUTION: Do not use abrasive chemicals or compounds on painted surfaces. Damage to finish can result.**

**Do not use harsh alkaline based cleaning solvents on painted surfaces. Damage to finish or color can result.**

### FINESSE SANDING, BUFFING, AND POLISHING

#### DESCRIPTION

Minor acid etching, orange peel, or smudging in clear coat or single-stage finishes can be reduced with light finesse sanding, hand buffing, and polishing. **If the finish has been finesse sanded in the past, it cannot be repeated. Finesse sanding operation should be performed by a trained automotive paint technician.**

## DESCRIPTION AND OPERATION (Continued)

**CAUTION: Do not remove clear coat finish, if equipped. Base coat paint must retain clear coat for durability.**

**PAINTED SURFACE TOUCH-UP****DESCRIPTION**

When a painted metal surface has been scratched or chipped, it should be touched-up as soon as possible to avoid corrosion. For best results, use Mopar® Scratch Filler/Primer, Touch-Up Paints and Clear Top Coat. Refer to Introduction group of this manual for Body Code Plate information.

**WARNING: USE A OSHA APPROVED BREATHING FILTER WHEN SPRAYING PAINT OR SOLVENTS IN A CONFINED AREA. PERSONAL INJURY CAN RESULT.**

**OPERATION**

- (1) Scrape loose paint and corrosion from inside scratch or chip.
- (2) Clean affected area with Mopar® Tar/Road Oil Remover, and allow to dry.
- (3) Fill the inside of the scratch or chip with a coat of filler/primer. Do not overlap primer onto good sur-

face finish. The applicator brush should be wet enough to puddle-fill the defect without running. Do not stroke brush applicator on body surface. Allow the filler/primer to dry hard.

(4) Cover the filler/primer with color touch-up paint. Do not overlap touch-up color onto the original color coat around the scratch or chip. Butt the new color to the original color, if possible. Do not stroke applicator brush on body surface. Allow touch-up paint to dry hard.

(5) On vehicles without clear coat, the touch-up color can be lightly finesse sanded (1500 grit) and polished with rubbing compound.

(6) On vehicles with clear coat, apply clear top coat to touch-up paint with the same technique as described in Step 4. Allow clear top coat to dry hard. If desired, Step 5 can be performed on clear top coat.

**WARNING: AVOID PROLONGED SKIN CONTACT WITH PETROLEUM OR ALCOHOL – BASED CLEANING SOLVENTS. PERSONAL INJURY CAN RESULT.**

**AVOID PROLONGED SKIN CONTACT WITH PETROLEUM OR ALCOHOL – BASED CLEANING SOLVENTS. PERSONAL INJURY CAN RESULT.**

## SPECIFICATIONS

## AFTER MARKET PAINT REPAIR PRODUCTS

## EXTERIOR COLOR

EXTERIOR COLOR	DAIMLER CHRYSLER CODE *	PPG	DuPONT	S-W** M-S**	AKZO NOBEL SIKKENS	SPIES HECKER	ICI**
Sienna Tinted Pearl Coat	WUL	5477	F7938	56687/ 56688	CHA99:WUL		LFF5B
Shale Green Metallic Clear Coat	XGR	5577	F9239	57765	CHA00:XGR	66088	PVJ8B
Flame Red Clear Coat	PR4	4679	B9326	46916	CHA93:PR4	30116	2NN6B
Champagne Pearl Coat	WTH	5475	B9882	57056	CHA99:WTH	22548	LLY7B
Everglade Pearl Coat	WPT	5472	F8200	56686	CHA99:WPT	65522	LEC8B
Silverstone Pearl Coat	XS5						
Black Clear Coat	DX8	9700	99	34858 90-5950	CHA85:DX8	73328	TC60B
Taupe Frost Pearl Coat	TTK	5244	B9750	52567	CHA97:TTK	80595	FNE5B
Stone White Clear Coat	SW1	83542	B9622	51540	CHA96:SW1	15069	8KY5B
Patriot Blue Pearl Coat	WBT	5512	F7991	56683	CHA99:WB7	56580	LEC6B

## INTERIOR COLOR

INTERIOR COLOR	DAIMLER CHRYSLER CODE	PPG	DuPONT	S-W** M-S**	AKZO NOBEL SIKKENS	SPIES HECKER	ICI**
Agate	AZ	9856/2- 1461	C9208	45994	CHALAZI	75016	7WCB
Camel	K5	27731/ 2-1584	C9603	51541	CHARK5I	81796	7VX6
Taupe	L5	28653/ 2-1652	C9873	54420	CHARL5I		KXE6

**NOTE: \*Herberts Standox and BASF use the Chrysler paint code as listed on the Body Code Plate and the Vehicle Safety Certification label. \*\***

**S-W = Sherwin-Williams, M-S = Martin Senour, ICI = ICI Autocolor.**

# STATIONARY GLASS

## TABLE OF CONTENTS

	page		page
<b>DESCRIPTION AND OPERATION</b>		<b>REMOVAL AND INSTALLATION</b>	
STATIONARY GLASS . . . . .	4	WINDSHIELD . . . . .	4
<b>SERVICE PROCEDURES</b>		QUARTER WINDOW GLASS . . . . .	6
WINDSHIELD SAFETY PRECAUTIONS . . . . .	4		

## DESCRIPTION AND OPERATION

### STATIONARY GLASS

#### DESCRIPTION

Windshields are made of two pieces of glass with a plastic inner layer. Windshields and selected stationary glass are structural members of the vehicle. The windshield glass is bonded to the windshield frame with urethane adhesive.

#### OPERATION

Windshields and other stationary glass protect the occupants from the effects of the elements. Windshields are also used to retain some airbags in position during deployment. Urethane bonded glass is difficult to salvage during removal. The urethane bonding is difficult to cut or clean from any surface. Before removing the glass, check the availability of replacement components.

### SERVICE PROCEDURES

#### WINDSHIELD SAFETY PRECAUTIONS

#### DESCRIPTION

**WARNING: DO NOT OPERATE THE VEHICLE WITHIN 24 HOURS OF WINDSHIELD INSTALLATION. IT TAKES AT LEAST 24 HOURS FOR URETHANE ADHESIVE TO CURE. IF IT IS NOT CURED, THE WINDSHIELD MAY NOT PERFORM PROPERLY IN AN ACCIDENT.**

**URETHANE ADHESIVES ARE APPLIED AS A SYSTEM. USE GLASS CLEANER, GLASS PREP SOLVENT, GLASS PRIMER, PVC (VINYL) PRIMER AND PINCH WELD (FENCE) PRIMER PROVIDED BY THE ADHESIVE MANUFACTURER. IF NOT, STRUCTURAL INTEGRITY COULD BE COMPROMISED.**

**DAIMLERCHRYSLER DOES NOT RECOMMEND GLASS ADHESIVE BY BRAND. TECHNICIANS SHOULD REVIEW PRODUCT LABELS AND TECHNICAL**

**DATA SHEETS, AND USE ONLY ADHESIVES THAT THEIR MANUFACTURERS WARRANT WILL RESTORE A VEHICLE TO THE REQUIREMENTS OF FMVSS 212. TECHNICIANS SHOULD ALSO INSURE THAT PRIMERS AND CLEANERS ARE COMPATIBLE WITH THE PARTICULAR ADHESIVE USED.**

**BE SURE TO REFER TO THE URETHANE MANUFACTURER'S DIRECTIONS FOR CURING TIME SPECIFICATIONS, AND DO NOT USE ADHESIVE AFTER ITS EXPIRATION DATE.**

**VAPORS THAT ARE EMITTED FROM THE URETHANE ADHESIVE OR PRIMER COULD CAUSE PERSONAL INJURY. USE THEM IN A WELL-VENTILATED AREA.**

**SKIN CONTACT WITH URETHANE ADHESIVE SHOULD BE AVOIDED. PERSONAL INJURY MAY RESULT.**

**ALWAYS WEAR EYE AND HAND PROTECTION WHEN WORKING WITH GLASS.**

**CAUTION: Protect all painted and trimmed surfaces from coming in contact with urethane or primers.**

**Be careful not to damage painted surfaces when removing moldings or cutting urethane around windshield.**


## REMOVAL AND INSTALLATION

### WINDSHIELD

#### REMOVAL

- (1) Remove inside rear view mirror.
- (2) Remove cowl cover.
- (3) Remove screws attaching windshield side molding to A-pillar (Fig. 1).
- (4) Remove upper windshield molding.
- (5) Cut urethane bonding from around windshield using a suitable sharp cold knife. A pneumatic cutting device can be used if available (Fig. 2).
- (6) Separate windshield from vehicle.


REMOVAL AND INSTALLATION (Continued)



80500535

**Fig. 1 Windshield**

- |                    |                       |
|--------------------|-----------------------|
| 1 - SIDE MOLDING   | 7 - BLOCKER           |
| 2 - SUPPORT SPACER | 8 - STUD              |
| 3 - UPPER MOLDING  | 9 - SUPPORT SPACER    |
| 4 - SIDE MOLDING   | 10 - WINDSHIELD       |
| 5 - ROOF PANEL     | 11 - ALIGNMENT SPACER |
| 6 - SUPPORT SPACER |                       |



**Fig. 2 Cut Urethane Around Windshield—Typical**

- |                |
|----------------|
| 1 - COLD KNIFE |
| 2 - WINDSHIELD |

## REMOVAL AND INSTALLATION (Continued)

## INSTALLATION

**WARNING: REVIEW ALL WARNINGS AND CAUTIONS IN THIS GROUP BEFORE PRECEDING WITH INSTALLATION.**

**CAUTION: Open a window before installing windshield. This will avoid pressurizing the passenger compartment. If a door or liftgate is slammed before urethane is cured, water leaks can result.**

The windshield fence should be cleaned of old urethane bonding material. Support spacers should be cleaned and properly installed on weld studs or repair screws at bottom of windshield opening.

(1) Place replacement windshield into windshield opening. Position glass in the center of the opening against the support spacers. Mark the glass at the support spacers with a grease pencil or masking tape and ink pen to use as a reference for installation. Remove replacement windshield from windshield opening (Fig. 3).

(2) Position the windshield inside up on a suitable work surface with two padded, wood 10 cm by 10 cm by 50 cm (4 in. by 4 in. by 20 in.) blocks, placed parallel 75 cm (2.5 ft.) apart (Fig. 4).

(3) Clean inside of windshield with Mopar Glass Cleaner and lint-free cloth.

(4) Apply clear glass primer 25 mm (1 in.) wide around edge of windshield. Wipe with clean/dry lint-free cloth.

(5) Apply black-out primer 15 mm (.75 in.) wide on top and sides of windshield and 25 mm (1 in.) on bottom of windshield. Allow at least three minutes drying time.

(6) Position windshield spacers on lower fence above support spacers at the edge of the windshield opening (Fig. 1).

(7) Apply a 10 mm (0.4 in.) bead of urethane around perimeter of windshield along the inside of the moldings. Apply two beads along the bottom edge.

(8) Install upper molding onto windshield.

(9) Apply fence primer around the perimeter of the windshield opening fence. Allow at least 18 minutes drying time.

(10) With aid of a helper, position windshield over windshield opening. Align reference marks at bottom of windshield to support spacers.

(11) Slowly lower windshield glass to windshield opening fence. Guide top molding into proper position if necessary. Push windshield inward to fence spacers at bottom and until top molding is flush to roof line.


(12) Clean excess urethane from exterior with Mopar Super Clean or equivalent.

(13) Install windshield side moldings.

(14) Install cowl cover and wipers.


(15) Install inside rear view mirror.

(16) After urethane has cured, water test windshield to verify repair.



**Fig. 3 Center Windshield and Mark at Support Spacers**

- 1 - A-PILLAR
- 2 - WINDSHIELD
- 3 - MARKS
- 4 - SUPPORT SPACER
- 5 - COWL



**Fig. 4 Work Surface Set up and Molding Installation**

- 1 - WINDSHIELD AND MOULDINGS
- 2 - URETHANE BEAD AROUND GLASS 7mm (.3 in.) FROM EDGE
- 3 - BLOCKS

## QUARTER WINDOW GLASS

## REMOVAL

(1) Cut urethane bonding from around quarter window glass using a suitable sharp cold knife. A pneumatic cutting device can be used if available.

(2) Separate glass from vehicle.

## REMOVAL AND INSTALLATION (Continued)

## INSTALLATION

**CAUTION:** Open a window before installing glass. This will avoid pressurizing the passenger compartment. If a door or liftgate is slammed before urethane is cured, water leaks can result.

The window opening fence should be cleaned of old urethane bonding material.


(1) Clean inside of glass with Mopar Glass Cleaner and lint-free cloth.

(2) Apply PVC (vinyl) primer 25 mm (1 in.) wide around edge of glass. Wipe with clean/dry lint-free cloth.

(3) Apply fence primer around edge of fence. Allow at least eighteen minutes drying time.

(4) Apply a 10 mm (0.4 in.) bead of urethane around window vinyl border location.

Position glass into window opening and lock clips into place (Fig. 5).



804d8ede

**Fig. 5 Quarter Window Glass**

- 1 - CLIP
- 2 - ROOF PANEL
- 3 - QUARTER WINDOW GLASS

# POWER SUNROOF

## TABLE OF CONTENTS

	page		page
<b>DESCRIPTION AND OPERATION</b>		SUNROOF EXPRESS MODULE . . . . .	12
SUNROOF OPERATION . . . . .	8	SUNROOF DRIVE MOTOR . . . . .	13
<b>DIAGNOSIS AND TESTING</b>		SUNROOF GLASS PANEL TIMING . . . . .	13
DIAGNOSTIC PROCEDURES . . . . .	8	SUNROOF SUNSHADE . . . . .	13
<b>REMOVAL AND INSTALLATION</b>		SUNROOF HOUSING ASSEMBLY . . . . .	14
SUNROOF WIND DEFLECTOR . . . . .	11	<b>ADJUSTMENTS</b>	
SUNROOF GLASS PANEL . . . . .	11	SUNROOF GLASS PANEL ADJUSTMENT . . . . .	14
DRAIN TUBE . . . . .	11		

### DESCRIPTION AND OPERATION

#### SUNROOF OPERATION

**WARNING:** Keep fingers and other body parts out of sunroof opening at all times.

The sunroof features a power sliding glass panel and a sunshade which can be manually positioned anywhere along its travel, rearward of glass panel front edge.

The sunroof is electrically operated from a switch located on the mini overhead console. To operate the sunroof the ignition switch must be in the On/Run position. The sunroof has both manual and Express Open modes of operation when opening. To open the sunroof in the Express Open mode, the switch is pressed rearward for less than **1 second**. This causes the sunroof glass to automatically retract and stop at a position slightly forward of full open that reduces low speed wind buffeting. The sunroof can also be opened manually by pressing and holding the switch rearward. Once the switch is held rearward for more than **1 second**, the glass will retract in the manual mode. Releasing the switch at any time during travel will cause the sunroof to stop at the current position.

To close the sunroof from an open position, the switch must be pushed forward and held until the sunroof glass comes to a complete stop. Releasing the switch at any time in this mode will cause the sunroof to stop at the current position.

To vent the sunroof from the closed position, the switch is pushed forward and held. Releasing the switch at any time during travel will cause the sunroof to stop at the current vent position. To reach the fully vented position, continue to hold the switch forward until vent motion stops. To close the sunroof from the vent position, push and hold the switch rearward until the glass comes to a complete stop.

### DIAGNOSIS AND TESTING

#### DIAGNOSTIC PROCEDURES

**CAUTION:** The sunroof motor is only to be powered through the vehicle battery and vehicle wire harness. Applying power to the sunroof motor leads will cause failure of the sunroof control unit.

Before beginning sunroof diagnostics verify that all other power accessories are in proper operating condition. Refer to Sunroof Diagnostic Chart for possible causes. If not, a common electrical problem may exist. Refer to Group 8W, Wiring Diagrams, of this publication for circuit, splice and component descriptions. Check the condition of the circuit protection (20 amp high current fuse (battery feed) located in the Power Distribution Center (PDC). Check the cover of the PDC for location of the fuse. Check for correct operation of the sunroof delay relay. Inspect all wiring connector pins for proper engagement and continuity. Check for battery voltage at battery and ignition pins of the power sunroof express module wiring connector. Refer to Group 8W, Wiring Diagrams, for circuit information. The controller will not operate at less than 10 volts. Check the ground at the sunroof express module.

Before beginning diagnosis for wind noise or water leaks, verify that the problem was not caused by releasing the control switch before the sunroof was fully closed. The sunroof module has a water-management system. During washing high-pressure water may be forced between the glass panel seal and the roof opening. Normally this water will drain. However, when some type of drying blower system is used, like those found in automatic car washes, the water may not have a chance to drain before the blower forces air between the seal and the roof opening. This causes the water to blow over the edge of the module and onto the headlining.

Refer to (Fig. 1) Sunroof Assembly for exploded view of the sunroof.




## DIAGNOSIS AND TESTING (Continued)

*SUNROOF DIAGNOSIS CHART*

SYMPTOM	POSSIBLE CAUSE
Sunroof motor inoperative.	Faulty control switch. Faulty circuit ground between sunroof express module, drive motor, control switch, and body harness. Faulty power circuit between sunroof express module, drive motor, switch, and body harness. Faulty sunroof drive motor. Faulty sunroof express module. Faulty sunroof drive motor connector.
Audible whine when switch is depressed, sunroof does not operate.	Faulty sunroof drive motor. Binding cable.
Audible clicking or ratcheting when switch is pressed, sunroof does not operate.	Broken or worn drive cable. Worn drive motor gear. Mechanisms not synchronized.
Sunroof vents and opens, but does not close.	Binding cable. Faulty circuit. Faulty control switch. Faulty sunroof express module. Faulty drive motor.
Sunroof vents, but does not open.	Binding linkage. Faulty circuit. Faulty switch. Faulty sunroof controller. Faulty drive motor.
Sunroof does not vent	Binding cable. Faulty circuit. Faulty control switch. Faulty sunroof express module.
Sunroof water leak.	Drain tubes cut, disconnected, clogged or kinked. Drain tube grommet loose at floorpan. Glass panel improperly adjusted. Faulty glass panel seal.
Wind noise from sunroof.	Front of glass panel too high or rear too low. Glass panel not centered in opening. Faulty glass panel seal. Roof rack crossbar too close to rear of sunroof opening.
Rattles from open sunroof while driving	Loose or broken attaching hardware. Worn or broken mechanism.
Rattles from closed sunroof while driving	Loose or broken attaching hardware. Worn or broken mechanism. Loose wiring or wiring components.

# REMOVAL AND INSTALLATION



**Fig. 1 Sunroof Assembly**

REMOVAL AND INSTALLATION (Continued)

- |                    |                    |
|--------------------|--------------------|
| 1 - SUNSHADE       | 5 - WIND DEFLECTOR |
| 2 - EXPRESS MODULE | 6 - GLASS PANEL    |
| 3 - DRIVE MOTOR    | 7 - DRAIN CHANNEL  |
| 4 - FRAME ASSEMBLY |                    |


**SUNROOF WIND DEFLECTOR**

**REMOVAL**

- (1) Open sunroof glass panel.
- (2) Push down one corner of the wind deflector and let the other corner rise up (Fig. 2).
- (3) Push the low corner towards the opposite side of the vehicle until tab on sunshade clears the body. Then raise the corner up.
- (4) Repeat the procedure to the other corner.
- (5) Lift wind deflector to 90% of the way.
- (6) Push the attaching ends of the deflector to the rear of the vehicle to disengage the deflector.

**INSTALLATION**

- (1) Place wind deflector at 90% in the vertical position to the sunroof. With the sunroof open.
- (2) Push ends of the deflector towards the front of the vehicle to engage ends.
- (3) Lower wind deflector to normal position.
- (4) Push one corner to the opposite side of the vehicle until tab clears vehicle body and lower deflector for that corner.
- (5) Push the side that was just installed completely down.
- (6) Push the opposite corner cross vehicle until tab clears the body. Then lower deflector to position.
- (7) Test sunroof operation.



**Fig. 2 Wind Deflector**

- 1 - WIND DEFLECTOR  
2 - TAB

**SUNROOF GLASS PANEL**


**REMOVAL**

- (1) Slide sunshade rearward to the open position.
- (2) Move the glass panel to the fully closed position.
- (3) Remove the four attaching screws (Fig. 3).
- (4) Lift off glass panel and remove from vehicle.

**INSTALLATION**

**NOTE:** Sunroof glass must be set in place and attached as close as possible to flush with the roof surface. For wind noise reasons, care must be taken to ensure that the glass is not remounted either a) Overflush to the roof surface at the front edge of the glass, or b) Underflush to the roof surface at the rear edge of the glass.

- (1) Position glass panel in to opening.
- (2) Start the four attaching screws.
- (3) Tighten screws.
- (4) Verify sunroof operation and alignment. Check fit and adjust as necessary, refer to Sunroof Glass Panel Adjustment for proper procedures.



**Fig. 3 Sunroof Glass Panel Removal**

- 1 - ATTACHING SCREW

**DRAIN TUBE**

**REMOVAL**

- (1) Remove the headliner to access clamps attaching drain tube to sunroof (Fig. 4).

## REMOVAL AND INSTALLATION (Continued)

(2) Disengage clamps attaching drain tube to sunroof.

(3) Tape the end of the old drain tube to the new drain tube. Ensure that the tape build up on the tube ends is not excessive.

(4) Remove front/rear trim panels as necessary to disengage clamps securing drain tube to body.

(5) Remove the drain tube plug from the underside of the vehicle.

(6) From the underside of the vehicle carefully, pull/route the drain tube through the body panel. Applying a soapy water solution to the new tube may aid in this procedure.

## INSTALLATION

(1) Install the plug adapter to the bottom of the drain tube.

(2) Engage clamps securing drain tube to body (Fig. 4).

(3) Install front/rear trim panels as necessary.

(4) Install drain tube to sunroof and engage clamp.

(5) Install the headliner.

## SUNROOF EXPRESS MODULE

## REMOVAL

(1) Move the glass panel to the fully closed position.

(2) Remove A-pillar trim, sun visors, and map lamp/mini console.

(3) Lower headliner as necessary to gain access to the sunroof express module.

(4) Disconnect the express module wire harness connectors.

(5) Remove express module screw.

(6) Remove express module from the keyway by sliding module towards the center of the vehicle.


## INSTALLATION

(1) Insert sunroof express module in the keyway located in the sunroof module and slide the module outward to lock it into position.

(2) Install the sunroof express module screw.

(3) Connect the wire connectors to the sunroof express module.

(4) Install the headliner into position.



SUNROOF DRAIN HOSE ROUTING

80b9a524

Fig. 4 Sunroof Drain Hose Routing

1 - DRAIN HOSE

2 - CLAMPS

3 - PLUG

4 - FLOOR

5 - CLAMPS

6 - DRAIN HOSE

## REMOVAL AND INSTALLATION (Continued)

- (5) Install the A-pillar trim, sun visors, and map lamp/mini console.
- (6) Test sunroof operation, adjust if necessary.

## SUNROOF DRIVE MOTOR

### REMOVAL


**NOTE:** The sunroof system is timed from the factory so that the motor shuts off automatically when the sunroof window reaches a certain position. Extreme care must be taken when removing the motor, timing may be thrown off causing possible damage to the sunroof system. Anytime the motor is removed from the sunroof assembly the sunroof glass panel must be in the **FULLY CLOSED POSITION** or the unit will be out of timing. The drive motor cannot be reset to the park position after being removed.

**CAUTION:** The sunroof motor should only be powered through the vehicle battery and sunroof wire harness. Applying power to the sunroof motor leads will cause failure of the control module.

- (1) Move glass panel to the fully closed position.
- (2) Remove A,B,C, and D-pillar trim, sun visors, and map lamps/mini console.
- (3) Disconnect the control switch wire connector.
- (4) Remove headliner as necessary to gain access to sunroof drive motor. Refer to Headliner Removal and Installation for proper procedures.
- (5) Disconnect the drive motor wire harness connectors (Fig. 5).
- (6) Remove drive motor fasteners and remove motor from the sunroof housing.

### INSTALLATION

- (1) Ensure that the window is in the fully closed position before mounting the motor. If motor fails with the window in the open position the sunroof glass panel timing will have to be timed. The new motor comes in the fully closed position and with a gage for setting cable timing. Refer to Sunroof Glass Panel Timing.
- (2) Place drive motor into position on the sunroof housing and install fasteners.
- (3) Connect express module, drive motor, and control switch wire connectors.
- (4) Set headliner into position.
- (5) Test sunroof operation, adjust as necessary.
- (6) Finish installing the headliner.
- (7) Connect the control switch wire connector.
- (8) Install A,B, C, and D-pillar trim, sun visors, and map lamps/mini console.



**Fig. 5 Sunroof Drive Motor and Express Module**

- 1 - EXPRESS MODULE
- 2 - SCREW

## SUNROOF GLASS PANEL TIMING

### Sunroof Drive Cable Timing

**NOTE:** A gage comes with the new motor.

- (1) If the glass panel was not in the fully closed position, when the motor was removed, the sunroof glass panel needs to be timed, before the new motor is installed.
- (2) Remove sunroof glass panel.
- (3) Set gage into the track near the rear of the opening between the driver slide and the bracket (Fig. 6).
- (4) Move the driver slide forward or aft to get proper setting.
- (5) Repeat the operation on the other side.
- (6) Install drive motor.

## SUNROOF SUNSHADE

### REMOVAL

- (1) Open sunroof approximately 50% of the way.
- (2) Push sunshade down until tabs clear glass.
- (3) Move sunshade forward of glass panel.
- (4) Compress the spring loaded plungers holding the guide blocks in the track.
- (5) Slide the sunshade forward while lifting the front through the opening until the rear guide blocks are accessible.


**CAUTION:** Use care not to crease the sunshade when removing or installing.

- (6) Disengage rear guide blocks from track.

### INSTALLATION

- (1) Install the sunshade from outside of the vehicle with the sunroof fully open.
- (2) Put rear guide blocks into sunshade guide track.

## REMOVAL AND INSTALLATION (Continued)



80b34e19

**Fig. 6 Sunroof Drive Cable Timing**

- 1 - MOVE DRIVER SLIDE FORWARD/AFT  
2 - GAGE

(3) Push sunshade back and down through the sunroof opening.

(4) Using a flat blade tool, put front guide blocks into the sunshade track. By pushing the block towards the center of the vehicle.

(5) Move the glass panel to approximately halfway to the fully closed position.


(6) Push sunshade down until the sunshade clears the glass then move sunshade rearward behind the glass panel.

**SUNROOF HOUSING ASSEMBLY****REMOVAL**

- (1) Move glass panel to the fully closed position.
- (2) Disconnect battery negative cable.
- (3) Recline both front seats.
- (4) Remove overhead console.
- (5) Remove headliner
- (6) Disconnect the drain tubes from sunroof housing (Fig. 7).
- (7) Loosen fasteners attaching sunroof housing assembly.
- (8) With the aid of a helper, remove fasteners attaching sunroof housing assembly to roof panel.

**INSTALLATION**

- (1) Raise the sunroof housing assembly and guide into position and start fasteners (Fig. 7).
- (2) Tighten the fasteners, front to rear, attaching the sunroof module to roof panel. Tighten the fasteners, front to rear, to 11 N·m (97 in. lbs.) torque.



80b9a523

**Fig. 7 SUNROOF ASSEMBLY**

- 1 - ROOF  
2 - DRAIN HOSE  
3 - CLAMP  
4 - SUNROOF ASSEMBLY  
5 - CLAMP  
6 - DRAIN HOSE

- (3) Connect the drain tubes to the sunroof housing.
- (4) Set headliner into position.
- (5) Connect express module, drive motor, and control switch wire connectors.
- (6) Test sunroof operation, adjust as necessary.
- (7) Finish installing the headliner.
- (8) Connect battery negative cable.

**ADJUSTMENTS****SUNROOF GLASS PANEL ADJUSTMENT**

- (1) Move the sunshade rearward to the open position.
- (2) Move the sunroof glass panel to the fully closed position.
- (3) Loosen the forward screws on each side enough to make the front adjustment.
- (4) Adjust the front of the sunroof glass panel 1 mm (1/32 inch) below the top surface of the roof panel.
- (5) Tighten the front two screws.
- (6) Loosen the rear screws on each side enough to make the rear adjustment.
- (7) Adjust the rear of the sunroof glass panel 1 mm (1/32 inch) above the top surface of the roof panel.
- (8) Tighten the rear two screws.
- (9) Check for proper fit. If not OK, repeat glass panel adjustment.

# SEATS

## TABLE OF CONTENTS

	page		page
<b>DESCRIPTION AND OPERATION</b>		REAR SEAT CUSHION.....	19
SEATS.....	15	REAR SEAT CUSHION COVER.....	19
<b>REMOVAL AND INSTALLATION</b>		REAR SEAT BACK LATCH RELEASE HANDLE ..	20
FRONT BUCKET SEAT.....	15	REAR SEATBACK.....	21
BUCKET SEAT SIDE SHIELD.....	16	REAR SEAT BACK LATCH/HINGE.....	21
BUCKET SEAT TRACK ADJUSTER.....	16	REAR SEAT BACK COVER.....	21
BUCKET SEAT RECLINER.....	16	REAR SEAT HEAD REST.....	22
BUCKET SEAT BACK.....	16	REAR SEAT FOLDING HEAD REST RELEASE	
BUCKET SEAT HEAD RESTRAINT.....	17	KNOB.....	22
BUCKET SEAT HEAD RESTRAINT SLEEVE.....	18	REAR SEAT HEAD REST SLEEVE.....	22
BUCKET SEAT BACK COVER.....	18	REAR SEAT HEAD REST FOLDING	
BUCKET SEAT CUSHION COVER.....	19	MECHANISM.....	22
REAR SEAT CUSHION RELEASE LATCH.....	19		

## DESCRIPTION AND OPERATION

### SEATS

#### DESCRIPTION

Seat modules are made up of a seat frame, seat cushion, seat back cushion, a covering material, and the electrical components used for power operation, if equipped. Some seat systems also contain seat belt components and supplemental restraint systems.

#### OPERATION

Seat assemblies transport the occupants in comfort and safety. Seat assemblies also help position occupants correctly in the event of airbag deployment. Seat cushions, coverings, and electrical components are serviceable. Refer to the appropriate group in this manual.


## REMOVAL AND INSTALLATION

### FRONT BUCKET SEAT

#### REMOVAL

- (1) Move seat to full rearward position.
- (2) Remove front bolts attaching seat to floor pan (Fig. 1).
- (3) Move seat to full forward position.
- (4) Using a trim stick, pry cover from seat track (power seat only).
- (5) Remove rear bolts attaching seat to floor pan.
- (6) If equipped, disconnect power seat wire harness connector.

- (7) Remove seat from vehicle.



80b5cb24

**Fig. 1 Front Bucket Seat**

- 1 - POWER BUCKET SEAT
- 2 - FLOOR PAN
- 3 - SEAT TRACK COVER

#### INSTALLATION

- (1) Position seat on floor pan.
- (2) If equipped, connect power seat wire harness connector.
- (3) Install rear bolts attaching seat to floor pan. Tighten bolts to 40 N·m (30 ft. lbs.) torque.
- (4) If equipped, install cover on seat track.

## REMOVAL AND INSTALLATION (Continued)

- (5) Move seat to full rearward position.
- (6) Install front bolts attaching seat to floor pan. Tighten bolts to 40 N·m (30 ft. lbs.) torque.

## BUCKET SEAT SIDE SHIELD

## REMOVAL

- (1) Remove screws attaching side shield to seat frame.
- (2) Disconnect wire harness connectors from power seat and power lumbar switches, if equipped.
- (3) Separate side shield from seat.

## INSTALLATION

- (1) Position side shield on seat.
- (2) Connect wire harness connectors to power seat and power lumbar switches, if equipped.
- (3) Install screws attaching side shield to seat frame.

## BUCKET SEAT TRACK ADJUSTER

## REMOVAL

- (1) Remove seat.
- (2) Remove side shield.
- (3) Remove nuts attaching seat track adjuster to seat cushion frame (Fig. 2) and (Fig. 3). Roll cushion trim cover up to access the two front nuts.
- (4) Disengage clips attaching wire harness to adjuster.
- (5) Disengage seat memory module connector, if equipped.
- (6) Separate seat track from seat cushion frame.


## INSTALLATION

- (1) Transfer seat memory module, if equipped.
- (2) Position seat track on seat cushion frame.
- (3) Route harness through frame and engage clips attaching wire harness to adjuster.
- (4) Engage seat memory module connector, if equipped.
- (5) Install nuts attaching seat track adjuster to seat cushion frame. Tighten nuts to 28 N·m (20 ft. lbs.) torque.
- (6) Install front edge of cushion trim cover.
- (7) Install seat.

## BUCKET SEAT RECLINER

## REMOVAL

- (1) Remove seat back.
- (2) Disengage J-strap at base of seat back.
- (3) Roll seat back cover upward to access bolts attaching recliner to seat back frame.
- (4) Remove bolts attaching recliner to seat back frame.



80ba7810

Fig. 2 Seat Track Adjuster—Power

- 1 - BACK PANEL
- 2 - LUMBAR ASSEMBLY
- 3 - SEAT CUSHION FRAME
- 4 - POWER SEAT TRACK ADJUSTER
- 5 - POWER RECLINER
- 6 - SEAT CUSHION PAD
- 7 - SEAT BACK FRAME

- (5) Separate recliner from seat back.

## INSTALLATION

- (1) Position recliner on seat back.
- (2) Install bolts attaching recliner to seat back frame. Tighten bolts to 28 N·m (20 ft. lbs.) torque.
- (3) Roll seat back cover downward.
- (4) Engage J-strap at base of seat back.
- (5) Install seat back.


## BUCKET SEAT BACK

## REMOVAL

- (1) Move seat to full rearward position.



REMOVAL AND INSTALLATION (Continued)



80b6f0aa

**Fig. 3 Seat Track Adjuster — Manual**

- 1 - MANUAL RECLINER
- 2 - SEAT CUSHION PAD
- 3 - SEAT BACK FRAME
- 4 - SEAT CUSHION FRAME
- 5 - MANUAL SEAT TRACK ADJUSTER

- (2) Remove inboard bolt attaching seat back frame to seat cushion frame.
- (3) Move seat to full forward position.
- (4) Move seat back to full recline position.
- (5) Remove screws attaching seat side shield to seat frame.
- (6) Disconnect wire harness connector from recliner motor, if equipped.
- (7) From the underside of the seat, disconnect the wire harness connector for the power lumbar and/or heated seat, if equipped.
- (8) Remove outboard bolts attaching recliner to seat cushion frame.
- (9) Route the power lumbar and/or heated seat harness through the seat cushion cover, if equipped.

- (10) Separate seat back from seat cushion.


**INSTALLATION**

- (1) Position seat back on seat cushion.
- (2) Route the power lumbar and heater harness through the seat cushion cover, if equipped.
- (3) Install recliner bolts attaching seat back frame to seat cushion frame. Tighten bolts to 28 N·m (20 ft. lbs.) torque.
- (4) Install the inboard bolt attaching seat back frame to seat cushion frame. Tighten bolt to 47N·m (35 ft.lbs.).
- (5) Connect wire harness connector to recliner motor and/or heated seat, if equipped.
- (6) From the underside of the seat, connect the power lumbar and/or heated seat wire harness connector to the seat harness, if equipped.
- (7) Install screws attaching seat side shield to seat frame.

**BUCKET SEAT HEAD RESTRAINT**

**REMOVAL**

- (1) Depress head restraint release button and lift head restraint to full up position.
- (2) Using a small flat blade, depress tab on right side head restraint release button and using your hand, simultaneously press tab on left side head restraint release button (Fig. 4) and pull head restraint up to separate from seat back.



80b6f0a7

**Fig. 4 Head Restraint**

- 1 - HEAD RESTRAINT
- 2 - FLAT BLADE

**INSTALLATION**


- (1) Position head restraint in seat back, press tab on left side head restraint release button and push down head restraint to secure.

## REMOVAL AND INSTALLATION (Continued)

## BUCKET SEAT HEAD RESTRAINT SLEEVE

## REMOVAL

- (1) Remove head restraint.
- (2) Remove seat back.
- (3) Remove seat back cover.
- (4) Remove hog rings attaching cushion pad to seat back frame (Fig. 5).
- (5) Remove cushion pad from seat back frame.
- (6) Rotate head restraint sleeve 1/4 turn counter-clockwise to release retaining tab.
- (7) Pull sleeve from seat back frame (Fig. 6).



80b6f0a4

Fig. 5 Cushion Pad

- 1 - HOG RING
- 2 - SEAT BACK CUSHION PAD


## INSTALLATION

- (1) Position sleeve in seat back frame.
- (2) Rotate head restraint sleeve 1/4 turn clockwise to engage retaining tab.
- (3) Install cushion pad onto seat back frame.
- (4) Install hog rings attaching cushion pad to seat back frame.
- (5) Install seat back cover.
- (6) Install seat back.
- (7) Install head restraint.

## BUCKET SEAT BACK COVER

## REMOVAL

- (1) Remove head restraint.
- (2) Using a trim stick, carefully pry head restraint release button caps from the top of seat back.




80b6f0a5

Fig. 6 Head Restraint Sleeve

- 1 - HEAD RESTRAINT SLEEVE
- 2 - SEAT BACK FRAME
- 3 - RETAINING TAB

- (3) Remove seat back.
- (4) Disengage J-strap at base of seat back.
- (5) Slide hand between the face of the seat back pad and the cushion cover and carefully separate hook and loop fastener (Fig. 7).
- (6) Roll cover upward and disengage hog rings.
- (7) Roll cover upward to top of seat back.
- (8) Separate cover from seat back.



80b6f0a8

Fig. 7 Seat Back Cover

- 1 - SEAT BACK COVER
- 2 - HOOK AND LOOP FASTENER
- 3 - SEAT BACK PAD

## INSTALLATION

- (1) Position cover inside-out at the top of seat back.
- (2) Roll cover downward.
- (3) Engage hog rings.

REMOVAL AND INSTALLATION (Continued)

- (4) Align seat back cover with hook and loop fasteners and secure.
- (5) Roll cover downward.
- (6) Engage J-strap at base of seat back.
- (7) Install seat back.


**NOTE:** The taller head restraint release button cap is positioned on the left hand side and the head restraint button cap with the hidden button is positioned on the right hand side.

- (8) Position head restraint release button caps on head restraint sleeves and press to secure.
- (9) Install head restraint.

**BUCKET SEAT CUSHION COVER**

**REMOVAL**

- (1) Remove seat from vehicle.
- (2) Remove seat back.
- (3) Disengage J-straps attaching cushion cover to seat cushion frame.
- (4) Disengage hog rings attaching cushion cover to cushion frame at rear of seat along bottom of cushion cover (Fig. 8).
- (5) Roll up edges of cover and route seat function switches through access hole on outboard side of seat cushion, if equipped.
- (6) Disengage seat cushion heater element connector, if equipped.
- (7) Disengage hog rings attaching cover to cushion along cover insert.
- (8) Separate seat cushion cover from seat cushion.



80b6f0a6

**Fig. 8 Seat Cushion Cover**

- 1 - HOG RING
- 2 - CUSHION COVER

**INSTALLATION**

- (1) Position seat cover on cushion.

- (2) Engage hog rings attaching cushion cover to cushion along insert.
- (3) Engage seat cushion heater element connector, if equipped.
- (4) Route seat function switches through access hole on outboard side of seat cushion, if equipped.
- (5) Engage J-straps attaching cushion cover to seat cushion frame.
- (6) Engage hog rings attaching cushion cover to cushion frame.
- (7) Install seat back.
- (8) Install seat.

**REAR SEAT CUSHION RELEASE LATCH**

**REMOVAL**

- (1) Unlatch seat and pivot seat upward.
- (2) Disengage J-strap at seat cushion base panel.
- (3) Roll back cushion cover.
- (4) Remove screws attaching latch to base panel.
- (5) Separate latch from base panel.

**INSTALLATION**

- (1) Position latch on base panel.
- (2) Install screws attaching latch to base panel. Tighten screws to 8 N·m (75 in. lbs.) torque.
- (3) Route the cushion release strap from the loop on the latch through the slot in the trim cover.
- (4) Engage J-strap at seat cushion base panel.
- (5) latch seat.

**REAR SEAT CUSHION**

**REMOVAL**

- (1) Disengage seat cushion at rear by pulling upward on release strap.
- (2) Remove bolts attaching seat cushion to floor pan (Fig. 9).
- (3) Remove seat cushion from vehicle.

**INSTALLATION**


- (1) Position seat cushion in vehicle.
- (2) Install bolts attaching seat cushion to floor pan. Tighten bolts to 11 N·m (8 ft. lbs.) torque.
- (3) Lock seat cushion down by pressing firmly on center of cushion until latch engages.

**REAR SEAT CUSHION COVER**

**REMOVAL**

- (1) Remove rear seat cushion.
- (2) From the underside of the seat, disengage J-straps attaching cover to seat cushion base panel.
- (3) Remove push-in fasteners attaching cushion cover to seat cushion base panel (Fig. 10).
- (4) Roll back cover.

## REMOVAL AND INSTALLATION (Continued)




80b5cb26

**Fig. 9 Rear Seat Cushion**

- 1 - SEAT CUSHION  
2 - FLOOR PAN

(5) Disengage hog rings attaching cushion cover to seat cushion foam pad.

(6) Separate cushion cover from seat cushion foam pad.



80b76ee9

**Fig. 10 Push-in Fasteners**

- 1 - CUSHION COVER  
2 - SEAT CUSHION BASE PANEL  
3 - PUSH-IN FASTENER

**INSTALLATION**

(1) Position cushion cover on seat cushion foam pad.

(2) Engage hog rings attaching cushion cover to seat cushion foam pad.

(3) Align cushion cover and engage J-straps attaching cushion cover to seat cushion base panel.

(4) Install push-in fasteners attaching cushion cover to seat cushion base panel.

(5) Install rear seat cushion.

**REAR SEAT BACK LATCH RELEASE HANDLE****REMOVAL**

(1) Pull handle to release latch.


(2) Remove screws attaching release handle to seat back frame.

(3) Using a small flat blade, disengage retainers securing latch release cable housing to latch release handle.

(4) Rotate cable end until barrel end aligns with key hole slot in latch release handle.

(5) Disengage cable barrel end from release handle.

(6) Separate latch release handle from seat back (Fig. 11).



80ba780a

**Fig. 11 Rear Seat Release Handle**

- 1 - REAR SEAT FOLDING RELEASE HANDLE

**INSTALLATION**

(1) Route cable end into latch release handle.

(2) Rotate cable end until barrel end aligns with key hole slot in latch release handle and insert into handle.

(3) Engage retainers securing latch release cable housing to latch release handle.

(4) Position latch release handle in seat back. Ensure seat back cover is properly aligned.


(5) Install screws attaching release handle to seat back frame.

## REMOVAL AND INSTALLATION (Continued)

## REAR SEATBACK

## REMOVAL

- (1) Move rear seat cushions to forward cargo position.
- (2) Remove bolts attaching seatback side support bracket to floor pan (right side) (Fig. 12).
- (3) Tilt seatback forward, and slide it outboard to detach it from pin on center pivot bracket.
- (4) Remove right side (60%) seatback from vehicle.
- (5) Remove bolts attaching seatback side support bracket and center pivot bracket to floor pan (left side).
- (6) Remove left side (40%) seatback from vehicle.



**Fig. 12 Rear Seat Back**

- 1 - SEAT BACK
- 2 - FLOOR PAN
- 3 - CENTER PIVOT BRACKET
- 4 - SIDE SUPPORT BRACKET

## INSTALLATION

- (1) Position left side (40%) seatback in vehicle.
- (2) Position left side support bracket and center pivot bracket with bolt holes aligned and install bolts. Tighten bolts to 28 N·m (20 ft. lbs.) torque.
- (3) Position right side (60%) seatback in vehicle.
- (4) Install seatback onto center pivot bracket pin. Ensure seat back is properly engaged on the center pivot pin.
- (5) Position right side support bracket with bolt holes aligned and install bolts. Tighten bolts to 28 N·m (20 ft. lbs.) torque.
- (6) Return seat cushions to seating position.

## REAR SEAT BACK LATCH/HINGE

## REMOVAL

- (1) Remove seat back.
- (2) Disengage J-straps on outboard side of seat back.
- (3) Disengage release cable from latch.
- (4) Remove bolts attaching latch/hinge to seat back frame.
- (5) Separate latch/hinge from seat back frame.

## INSTALLATION

- (1) Position latch/hinge on seat back frame.
- (2) Install bolts attaching latch/hinge to seat back frame. Tighten bolts to 28 N·m (20 ft. lbs.) torque.
- (3) Engage latch release cable.
- (4) Engage J-straps on outboard side of seat back.
- (5) Install seat back.

## REAR SEAT BACK COVER


## REMOVAL

- (1) Remove seat back.
- (2) Remove head restraint.
- (3) Remove head restraint caps.
- (4) Disengage J-straps on outboard side of seat back.
- (5) Disengage J-straps at base of seat back.
- (6) Remove screws attaching latch release handle to seat back frame.
- (7) Roll seat back cover upward.
- (8) Disengage hook and loop fasteners attaching seat back cover to seat back pad (Fig. 13).
- (9) Roll seat back cover upward and route latch release handle through seat back cover.
- (10) Separate seat back cover from seat back.
- (11) Separate seat back pad from seat back frame.

## INSTALLATION

- (1) Position seat back cover and pad on seat back frame.
- (2) Route latch release handle through seat back cover.
- (3) Roll seat back cover partially downward aligning holes in seat back cover for head restraint and latch release handle.
- (4) Roll seat back cover downward align and engage hook and loop fasteners to seat back pad.
- (5) Engage J-straps at base of seat back.
- (6) Engage J-straps on outboard side of seat back.
- (7) Install screws attaching latch release handle to seat back frame.
- (8) Install head restraint.
- (9) Install seat back.

## REMOVAL AND INSTALLATION (Continued)



80b76ee7


**Fig. 13 Rear Seat Back Cover**

- 1 - SEAT BACK COVER
- 2 - SEAT BACK PAD
- 3 - HOOK AND LOOP FASTENER

**REAR SEAT HEAD REST****REMOVAL**

(1) Depress head rest release button and lift head rest to full up position.

(2) Using a small flat blade, depress tab on outboard side head rest release button and using your hand, simultaneously press tab on inboard side head rest release button (Fig. 14) and pull head rest up to separate from seat back.



80b6f0a7

**Fig. 14 Head Rest**

- 1 - HEAD RESTRAINT
- 2 - FLAT BLADE

**INSTALLATION**

(1) Position head rest in seat back, press tab on inboard side head rest release button cap and push down head restraint to secure.

**REAR SEAT FOLDING HEAD REST RELEASE KNOB**

The release knob is not salvageable during the removal process. The knob should only be replaced if damaged or broken. Check availability before servicing.

**REMOVAL**

(1) Using a E-XACTO knife or equivalent, cut the release knob from the release lever.

(2) Pull the release knob from the lever (Fig. 15).

**INSTALLATION**

(1) Position the release knob on the lever and press to snap in place.

**REAR SEAT HEAD REST SLEEVE****REMOVAL**

- (1) Remove seat back.
- (2) Remove head rest.
- (3) Remove head rest caps.
- (4) Remove seat back cover.
- (5) Rotate head rest sleeve 1/4 turn counter-clockwise to release retaining tab.
- (6) Pull sleeve from seat back frame.

**INSTALLATION**

- (1) Position sleeve in seat back frame.
- (2) Rotate head rest sleeve 1/4 turn clockwise to engage retaining tab.
- (3) Install seat back cover.
- (4) Install head rest caps.

**NOTE:** The head rest cap with the taller button is always on the inboard side of the seat back.

(5) Install the head rest.

**NOTE:** The folding head rest release knob is always on the outboard side.


(6) Install the seat back.

**REAR SEAT HEAD REST FOLDING MECHANISM****REMOVAL**

- (1) Remove the head rest.
- (2) Remove folding mechanism cover (Fig. 15).
- (3) Remove the screws that secure the head rest bun to the folding mechanism.

**NOTE:** The folding release knob is always located on the outboard side.

## REMOVAL AND INSTALLATION (Continued)



- (2) Install the folding mechanism cover.
- (3) Install the head restraint.

80ba7809

**Fig. 15 Rear Seat Head Rest Folding Mechanism**

- 1 - REAR SEAT HEAD REST FOLDING MECHANISM
- 2 - RELEASE KNOB
- 3 - FOLDING MECHANISM COVER

---

**INSTALLATION**

- (1) Position the head rest bun on the folding mechanism and install the screws.

# BODY COMPONENTS

## TABLE OF CONTENTS

	page		page
<b>DESCRIPTION AND OPERATION</b>		REAR DOOR CHECK . . . . .	42
BODY COMPONENTS . . . . .	25	REAR DOOR . . . . .	43
COMPONENT FASTENERS . . . . .	25	REAR DOOR HINGE . . . . .	43
<b>DIAGNOSIS AND TESTING</b>		REAR DOOR OUTSIDE HANDLE . . . . .	44
WATER LEAKS . . . . .	25	REAR DOOR LATCH . . . . .	44
WIND NOISE . . . . .	26	REAR DOOR LATCH STRIKER . . . . .	44
UNIVERSAL TRANSMITTER . . . . .	27	REAR DOOR INSIDE HANDLE ACTUATOR . . . . .	44
<b>SERVICE PROCEDURES</b>		REAR DOOR INNER BELT WEATHERSTRIP . . . . .	45
BODY LUBRICATION . . . . .	27	REAR DOOR OUTER BELT WEATHERSTRIP . . . . .	45
DRILLING AND WELDING PROCEDURES . . . . .	27	REAR DOOR OPENING WEATHERSTRIP . . . . .	45
<b>REMOVAL AND INSTALLATION</b>		REAR DOOR SECONDARY WEATHERSTRIP . . . . .	46
GRILLE . . . . .	27	REAR DOOR WINDOW REGULATOR . . . . .	46
HOOD SEAL . . . . .	28	REAR DOOR WINDOW GLASS . . . . .	47
HEADLAMP MOUNTING MODULE (HMM) . . . . .	28	REAR DOOR STATIONARY GLASS . . . . .	47
HOOD . . . . .	28	ROOF RAIL WEATHERSTRIP W/RETAINER . . . . .	48
HOOD INSULATION PANEL . . . . .	29	FUEL FILL DOOR . . . . .	48
HOOD SUPPORT PROP . . . . .	29	BODY SIDE CLADDING . . . . .	48
HOOD HINGE . . . . .	29	SILL MOLDING . . . . .	49
HOOD LATCH . . . . .	30	A-PILLAR TRIM . . . . .	50
HOOD RELEASE CABLE . . . . .	30	COWL LOWER TRIM . . . . .	50
COWL PLENUM SEAL . . . . .	31	OVERHEAD ASSIST HANDLE . . . . .	51
COWL COVER . . . . .	31	FRONT DOOR SCUFF PLATE . . . . .	51
EXTERIOR NAMEPLATES . . . . .	31	B-PILLAR UPPER TRIM . . . . .	51
SIDE VIEW MIRROR . . . . .	32	B-PILLAR LOWER TRIM . . . . .	51
SIDE VIEW MIRROR GLASS . . . . .	32	REAR DOOR SCUFF PLATE . . . . .	52
FRONT FENDER . . . . .	33	C-PILLAR UPPER TRIM . . . . .	53
FRONT DOOR TRIM PANEL . . . . .	34	QUARTER PANEL TRIM . . . . .	53
FRONT DOOR WATERDAM . . . . .	34	STORAGE BIN . . . . .	54
FRONT DOOR CHECK . . . . .	34	UPPER LIFTGATE OPENING TRIM . . . . .	54
FRONT DOOR . . . . .	35	D-PILLAR TRIM . . . . .	54
FRONT DOOR HINGE . . . . .	35	FRONT SHOULDER BELT . . . . .	55
FRONT DOOR OUTSIDE HANDLE . . . . .	36	FRONT SHOULDER BELT BUCKLE . . . . .	55
FRONT DOOR LOCK CYLINDER . . . . .	36	REAR SEAT SHOULDER BELT . . . . .	55
LOCK CYLINDERS . . . . .	37	REAR SEAT BELT BUCKLE . . . . .	55
FRONT DOOR LATCH . . . . .	37	FLOOR CONSOLE . . . . .	55
FRONT DOOR LATCH STRIKER . . . . .	37	FRONT CARPET . . . . .	56
FRONT DOOR INSIDE HANDLE ACTUATOR . . . . .	38	CARGO AREA CARPET . . . . .	57
FRONT DOOR INNER BELT SEAL . . . . .	38	REARVIEW MIRROR . . . . .	58
FRONT DOOR OUTER BELT SEAL . . . . .	38	REARVIEW MIRROR SUPPORT BRACKET . . . . .	58
FRONT DOOR GLASS RUN CHANNEL		SUNVISOR . . . . .	58
WEATHERSTRIP . . . . .	38	HEADLINER . . . . .	59
FRONT DOOR GLASS RUN CHANNEL . . . . .	39	LIFTGATE TRIM PANEL . . . . .	60
FRONT DOOR OPENING WEATHERSTRIP . . . . .	39	LOWER LIFTGATE OPENING TRIM PANEL . . . . .	60
FRONT DOOR SECONDARY WEATHERSTRIP . . . . .	39	LIFTGATE INSULATOR . . . . .	60
FRONT DOOR WINDOW REGULATOR . . . . .	40	LIFTGATE . . . . .	61
FRONT DOOR GLASS . . . . .	40	LIFTGATE HINGE . . . . .	62
REAR DOOR B-PILLAR SEAL . . . . .	41	LIFTGATE OUTSIDE HANDLE . . . . .	62
REAR DOOR TRIM PANEL . . . . .	41	LIFTGATE LATCH . . . . .	62
REAR DOOR WATERDAM . . . . .	42	LIFTGATE LATCH STRIKER . . . . .	62



LIFTGATE OPENING WEATHERSTRIP ..... 63  
 FLIP UP GLASS..... 64  
 FLIP UP GLASS WEATHERSTRIP ..... 64  
 FLIP UP GLASS SWITCH..... 64  
 FLIP UP GLASS LATCH..... 64  
 FLIP UP GLASS LATCH STRIKER ..... 66  
 LICENSE PLATE LAMP HOUSING ..... 66  
 D-PILLAR APPLIQUE ..... 66  
 D-PILLAR AIR EXHAUSTER..... 66  
 TAIL LAMP AIR EXHAUSTER..... 66  
 LUGGAGE RACK..... 67  
**ADJUSTMENTS**  
 HOOD ADJUSTMENT..... 67

DOOR ADJUSTMENT..... 67  
 DOOR LATCH ..... 67  
 LIFTGATE ADJUSTMENT..... 67  
**SPECIFICATIONS**  
 BODY LUBRICANTS ..... 68  
 WELD LOCATIONS ..... 69  
 SEALER LOCATIONS..... 118  
 STRUCTURAL ADHESIVE LOCATIONS ..... 135  
 BODY GAP AND FLUSH MEASUREMENTS .... 151  
 BODY OPENING DIMENSIONS ..... 153  
 TORQUE SPECIFICATIONS..... 156  
**SPECIAL TOOLS**  
 BODY..... 156

**DESCRIPTION AND OPERATION**

**BODY COMPONENTS**

**DESCRIPTION**

Exterior sheet metal components make up the exterior of the vehicle. Some exterior metal systems are welded assemblies, such as doors and hoods. Some exterior trim items are made of composite.

**OPERATION**

The exterior is finished in various metal stampings and composite moldings. These assemblies give the vehicle a finished appearance and protect the occupants from the elements. Some components are part of the energy absorbing system used to protect the occupants in collisions. The exterior sheet metal is repairable and adjustable for fit and finish. Welded and bonded component systems are adjustable as a system. Trim components made of composite are stamped with the type of material used. Daimler-Chrysler uses various fasteners to retain trim items. At times, it is not possible to remove trim items without damaging the fastener. If it is not possible to remove an item without damaging a component, cut or break the fasteners and use new ones when installing the component.

**COMPONENT FASTENERS**

DaimlerChrysler Corporation uses many different types of push-in fasteners to secure the interior and exterior trim to the body. Most of these fasteners can be reused to assemble the trim during various repair procedures. At times, a push-in fastener cannot be removed without damaging the fastener or the component it is holding. If it is not possible to remove a fastener without damaging a component or body, cut or break the fastener and use a new one when installing the component. Never pry or pound on a plastic or pressed-board trim component. Using a suitable fork-type prying device, pry the fastener from the retaining hole behind the component being

removed. When installing, verify fastener alignment with the retaining hole by hand. Push directly on or over the fastener until it seats. Apply a low-force pull to the panel to verify that it is secure.

When it is necessary to remove components to service another, it should not be necessary to apply excessive force or bend a component to remove it. Before damaging a trim component, verify hidden fasteners or captured edges holding the component in place.

**DIAGNOSIS AND TESTING**

**WATER LEAKS**

Water leaks can be caused by poor sealing, improper body component alignment, body seam porosity, missing plugs, or blocked drain holes. Centrifugal and gravitational force can cause water to drip from a location away from the actual leak point, making leak detection difficult. All body sealing points should be water tight in normal wet-driving conditions. Water flowing downward from the front of the vehicle should not enter the passenger or luggage compartment. Moving sealing surfaces will not always seal water tight under all conditions. At times, side glass or door seals will allow water to enter the passenger compartment during high pressure washing or hard driving rain (severe) conditions. Overcompensating on door or glass adjustments to stop a water leak that occurs under severe conditions can cause premature seal wear and excessive closing or latching effort. After completing a repair, water test vehicle to verify leak has stopped before returning vehicle to use.

**VISUAL INSPECTION BEFORE WATER LEAK TESTS**

Verify that floor and body plugs are in place, body drains are clear, and body components are properly aligned and sealed. If component alignment or sealing is necessary, refer to the appropriate section of this group for proper procedures.

## DIAGNOSIS AND TESTING (Continued)

## WATER LEAK TESTS

**WARNING: DO NOT USE ELECTRIC SHOP LIGHTS OR TOOLS IN WATER TEST AREA. PERSONAL INJURY CAN RESULT.**

When the conditions causing a water leak have been determined, simulate the conditions as closely as possible.

- If a leak occurs with the vehicle parked in a steady light rain, flood the leak area with an open-ended garden hose.
- If a leak occurs while driving at highway speeds in a steady rain, test the leak area with a reasonable velocity stream or fan spray of water. Direct the spray in a direction comparable to actual conditions.
- If a leak occurs when the vehicle is parked on an incline, hoist the end or side of the vehicle to simulate this condition. This method can be used when the leak occurs when the vehicle accelerates, stops or turns. If the leak occurs on acceleration, hoist the front of the vehicle. If the leak occurs when braking, hoist the back of the vehicle. If the leak occurs on left turns, hoist the left side of the vehicle. If the leak occurs on right turns, hoist the right side of the vehicle. For hoisting recommendations refer to Group 0, Lubrication and Maintenance, General Information section.

## WATER LEAK DETECTION

To detect a water leak point-of-entry, do a water test and watch for water tracks or droplets forming on the inside of the vehicle. If necessary, remove interior trim covers or panels to gain visual access to the leak area. If the hose cannot be positioned without being held, have someone help do the water test.

Some water leaks must be tested for a considerable length of time to become apparent. When a leak appears, find the highest point of the water track or drop. The highest point usually will show the point of entry. After leak point has been found, repair the leak and water test to verify that the leak has stopped.

Locating the entry point of water that is leaking into a cavity between panels can be difficult. The trapped water may splash or run from the cavity, often at a distance from the entry point. Most water leaks of this type become apparent after accelerating, stopping, turning, or when on an incline.

## MIRROR INSPECTION METHOD

When a leak point area is visually obstructed, use a suitable mirror to gain visual access. A mirror can also be used to deflect light to a limited-access area to assist in locating a leak point.

## BRIGHT LIGHT LEAK TEST METHOD

Some water leaks in the luggage compartment can be detected without water testing. Position the vehicle in a brightly lit area. From inside the darkened luggage compartment inspect around seals and body seams. If necessary, have a helper direct a drop light over the suspected leak areas around the luggage compartment. If light is visible through a normally sealed location, water could enter through the opening.

## PRESSURIZED LEAK TEST METHOD

When a water leak into the passenger compartment cannot be detected by water testing, pressurize the passenger compartment and soap test exterior of the vehicle. To pressurize the passenger compartment, close all doors and windows, start engine, and set heater control to high blower in HEAT position. If engine can not be started, connect a charger to the battery to ensure adequate voltage to the blower. With interior pressurized, apply dish detergent solution to suspected leak area on the exterior of the vehicle. Apply detergent solution with spray device or soft bristle brush. If soap bubbles occur at a body seam, joint, seal or gasket, the leak entry point could be at that location.

## WIND NOISE

Wind noise is the result of most air leaks. Air leaks can be caused by poor sealing, improper body component alignment, body seam porosity, or missing plugs in the engine compartment or door hinge pillar areas. All body sealing points should be airtight in normal driving conditions. Moving sealing surfaces will not always seal airtight under all conditions. At times, side glass or door seals will allow wind noise to be noticed in the passenger compartment during high cross winds. Over compensating on door or glass adjustments to stop wind noise that occurs under severe conditions can cause premature seal wear and excessive closing or latching effort. After a repair procedure has been performed, test vehicle to verify noise has stopped before returning vehicle to use.

Wind noise can also be caused by improperly fitted exterior moldings or body ornamentation. Loose moldings can flutter, creating a buzzing or chattering noise. An open cavity or protruding edge can create a whistling or howling noise. Inspect the exterior of the vehicle to verify that these conditions do not exist.

## VISUAL INSPECTION BEFORE TESTS

Verify that floor and body plugs are in place and body components are aligned and sealed. If component alignment or sealing is necessary, refer to the appropriate section of this group for proper procedures.

## DIAGNOSIS AND TESTING (Continued)

### ROAD TESTING WIND NOISE

(1) Drive the vehicle to verify the general location of the wind noise.

(2) Apply 50 mm (2 in.) masking tape in 150 mm (6 in.) lengths along weatherstrips, weld seams or moldings. After each length is applied, drive the vehicle. If noise goes away after a piece of tape is applied, remove tape, locate, and repair defect.

### POSSIBLE CAUSE OF WIND NOISE

- Moldings standing away from body surface can catch wind and whistle.
- Gaps in sealed areas behind overhanging body flanges can cause wind-rushing sounds.
- Misaligned movable components.
- Missing or improperly installed plugs in pillars.
- Weld burn through holes.

### UNIVERSAL TRANSMITTER

Universal Transmitter will operate most:

- Garage door opener
- Gate opener
- Home/Office lighting and/or security system(s)

The transmitter is powered by the M1 circuit that supplies voltage to the driver side visor/vanity lamp.

### TRAINING THE UNIVERSAL TRANSMITTER

To train the transmitter refer to the Owner's Manual.

### TESTING TRANSMITTER

(1) Check for battery voltage at the Universal Transmitter by pressing a button and seeing if a red lamp comes on. If OK, go to Step 6. If not OK, go to Step 2.

(2) Check if visor/vanity lamp lights. If lamp lights, replace visor. If lamp does not light go to Step 3.

(3) Check fuse. If OK, go to Step 4. If not OK, repair as necessary.

(4) Remove visor and test M1 wire for battery voltage at the visor connector. If voltage is OK, go to Step 5. If no voltage repair wire as necessary. Refer to Group 8W, Wiring Diagrams for proper terminals.

(5) Test Z1 wire for ground at the visor connector. If ground is OK, replace visor. If no ground repair wire as necessary.

(6) Check the instructions in the Owner's Manual and retrain the transmitter. If the transmitter can not be trained replace visor.

## SERVICE PROCEDURES

### BODY LUBRICATION

All mechanisms and linkages should be lubricated when necessary. This will maintain ease of operation and provide protection against rust and excessive wear. The weatherstrip seals should be lubricated to prolong their life as well as to improve door sealing.

All applicable exterior and interior vehicle operating mechanisms should be inspected and cleaned. Pivot/sliding contact areas on the mechanisms should then be lubricated.

(1) When necessary, lubricate the operating mechanisms with the specified lubricants.

(2) Apply silicone lubricant to a cloth and wipe it on door seals to avoid over-spray that can soil passenger's clothing.

(3) Before applying lubricant, the component should be wiped clean. After lubrication, any excess lubricant should be removed.

(4) The hood latch, latch release mechanism, latch striker, and safety latch should be lubricated periodically.

(5) The door lock cylinders should be lubricated twice each year (preferably autumn and spring).

- Spray a small amount of lock cylinder lubricant directly into the lock cylinder.
- Apply a small amount to the key and insert it into the lock cylinder.
- Rotate it to the locked position and then back to the unlocked position several times.
- Remove the key. Wipe the lubricant from it with a clean cloth to avoid soiling of clothing.

### DRILLING AND WELDING PROCEDURES

When holes must be drilled or punched in an inner body panel, verify depth of space to the outer body panel, electrical wiring, or other components. Damage to vehicle can result.

Do not weld exterior panels unless combustible material on the interior of vehicle is removed from the repair area. Fire or hazardous conditions, can result.

Always have a fire extinguisher ready for use when welding.

## REMOVAL AND INSTALLATION

### GRILLE

The grille is incorporated into the fascia. To replace or service the grille, the fascia must be removed. The grille is equipped with an insert which can be serviced.

## REMOVAL AND INSTALLATION (Continued)

## REMOVAL

- (1) Remove fascia.
- (2) Disengage retainers attaching grille insert to grille/fascia.
- (3) Separate grille insert from grille/fascia (Fig. 1).




Fig. 1 Grille Insert

- 1 - GRILLE/FASCIA  
2 - INSERT

## INSTALLATION

- (1) Position grille insert in grille/fascia.
- (2) Engage retainers attaching grille insert to grille/fascia.
- (3) Install fascia.

## HOOD SEAL

## REMOVAL

- (1) Raise hood.
- (2) Pull hood seal from upper radiator crossmember.
- (3) Separate seal from upper radiator crossmember (Fig. 2).

## INSTALLATION


- (1) Position seal on upper radiator crossmember.
- (2) Press seal onto upper radiator crossmember to seat.

## HEADLAMP MOUNTING MODULE (HMM)

## REMOVAL

**CAUTION:** Take special care when handling the HMM not to damage the upper mounting tabs. Step #3 must be performed prior to removing HMM from the vehicle to prevent damage to HMM.

- (1) Remove front fascia.



80b46b4e

Fig. 2 Hood Seal

- 1 - HOOD SEAL

- (2) Remove front wheelhouse splash shields.
- (3) Reach into the wheelhouse opening and disengage the retainer attaching the HMM to each side of the body.
- (4) Remove bolts attaching headlamp mounting module to body (Fig. 3).
- (5) Disconnect headlamp wire harness connectors.
- (6) Separate headlamp mounting module from vehicle.

## INSTALLATION


- (1) Position headlamp mounting module at vehicle.
- (2) Connect headlamp wire harness connectors.
- (3) Engage the retainer attaching the HMM to each side of the body.
- (4) Install bolts attaching headlamp mounting module to body (Fig. 3).
- (5) Install front wheelhouse splash shields.
- (6) Install front fascia.

## HOOD

## REMOVAL

- (1) Raise hood.
- (2) If equipped, disconnect underhood lamp harness connector. (Connector is located under cowl cover).
- (3) Using a wax crayon or equivalent, mark location of hood hinges on hood for installation alignment.
- (4) Support hood in the open position.
- (5) Remove hood support prop rods.
- (6) Remove bolts attaching hinges to hood.
- (7) With the aid of a helper, remove hood from vehicle.

## REMOVAL AND INSTALLATION (Continued)



80b46cd0

**Fig. 3 Headlamp Mounting Module**

1 - CONNECTOR  
2 - CONNECTOR

3 - MOUNTING BRACKET  
4 - HEADLAMP MODULE

**INSTALLATION**

- (1) Position hood on hinges.
- (2) Install bolts finger-tight.
- (3) Align hinges with installation reference marks and tighten bolts.
- (4) Install hood support prop rods.
- (5) Connect underhood lamp connector.
- (6) Inspect hood for proper alignment and adjust as necessary.

**HOOD INSULATION PANEL****REMOVAL**

- (1) Raise the hood.
- (2) Remove the insulation panel fasteners.
- (3) Remove the hood insulation panel.

**INSTALLATION**

- (1) Position the insulation panel on the underside of the hood.
- (2) Install the insulation panel fasteners.
- (3) Close the hood.

**HOOD SUPPORT PROP****REMOVAL**

- (1) Raise and support hood.
- (2) Using a small flat blade, pry the retainer attaching hood support prop to lower ball stud.
- (3) Slide retainer attaching hood support prop upper ball stud downward.
- (4) Disconnect hood support prop from lower ball stud and rotate support prop upward and disconnect from upper ball stud (Fig. 4).


**INSTALLATION**

- (1) Position hood support prop on upper ball stud.
- (2) Slide retainer upward to secure support prop to upper ball stud.
- (3) Position support prop on lower ball stud and press retainer inward to secure.

**HOOD HINGE****REMOVAL**

- (1) Raise and support hood.
- (2) Using a wax crayon or equivalent, mark position of hinge.


## REMOVAL AND INSTALLATION (Continued)



80b3c6fc

**Fig. 4 Hood Support Prop**

- 1 - HOOD
- 2 - COVER
- 3 - HINGE
- 4 - PROP



80b3c6ff

**Fig. 5 Hood Latch**

- 1 - HOOD RELEASE CABLE
- 2 - LATCH
- 3 - BUMPER

- (3) Remove hood hinge prop rod.
- (4) Remove nuts attaching hinge to hood (Fig. 4).
- (5) Remove bolts attaching hinge to body.
- (6) Separate hinge from vehicle.

**INSTALLATION**

- (1) Position hinge on vehicle and align reference marks.
- (2) Install bolts attaching hinge to body.
- (3) Install nuts attaching hinge to hood.
- (4) Install hood hinge prop rod.

**HOOD LATCH****REMOVAL**

- (1) Remove nuts attaching latch to radiator crossmember support (Fig. 5).
- (2) Disconnect hood release cable from latch.
- (3) Separate latch from vehicle.


**INSTALLATION**

- (1) Connect latch release cable to latch.
- (2) Position latch on radiator crossmember support.
- (3) Install nuts attaching latch to radiator crossmember support. Tighten nuts to 11 N·m (8 ft. lbs.) torque.

**HOOD RELEASE CABLE****REMOVAL**

- (1) Disconnect cable from hood latch (Fig. 6).
- (2) Disconnect cable from retaining clips on left inner fender panel.
- (3) Remove left cowl side trim panel.

- (4) Remove fasteners attaching cable bracket to cowl side panel (Fig. 7).
- (5) Route cable through dash panel and remove it from under instrument panel.



80b3c70a


**Fig. 6 Hood Latch**

- 1 - HOOD LATCH
- 2 - HOOD RELEASE CABLE

**INSTALLATION**

- (1) Route cable through hole in dash panel into engine compartment.
- (2) Pull cable forward and seat grommet in dash panel.
- (3) Position cable bracket on cowl side panel and install fasteners.
- (4) Install left cowl side trim panel.
- (5) Route and install cable in retaining clips on left inner fender panel.
- (6) Connect cable to hood latch.

REMOVAL AND INSTALLATION (Continued)



80b3c6fe


**Fig. 7 Hood Release Cable**

- 1 - LOWER COWL
- 2 - HOOD RELEASE CABLE
- 3 - RELEASE HANDLE

**COWL PLENUM SEAL**

**REMOVAL**

- (1) Raise hood.
- (2) Pull cowl plenum seal from cowl.
- (3) Separate cowl plenum seal from cowl (Fig. 8).



80b46b4d

**Fig. 8 Cowl Plenum Seal**

- 1 - PLENUM SEAL

**INSTALLATION**


- (1) Position cowl plenum seal on cowl.
- (2) Press cowl plenum seal to seat.

**COWL COVER**

**REMOVAL**

- (1) Remove wiper arms.
- (2) Remove plenum seal.

- (3) Remove plastic push nuts attaching cowl cover to cowl (Fig. 9).
- (4) Remove windshield washer tubes at connector.
- (5) Remove cowl cover from cowl.



80b46ae1

**Fig. 9 Cowl Cover**

- 1 - PLASTIC NUT
- 2 - COWL COVER

**INSTALLATION**

- (1) Position cowl cover on cowl.
- (2) Install windshield washer tubes at connector.
- (3) Install plastic push nuts attaching cowl cover to cowl.
- (4) Install plenum seal.
- (5) Install windshield wiper arms.

**EXTERIOR NAMEPLATES**

**REMOVAL**

**NOTE:** Exterior nameplates are attached to body panels with adhesive tape.

- (1) Apply a length of masking tape on the body, parallel to the top edge of the nameplate to use as a guide, if necessary.

- (2) If temperature is below 21°C (70°F) warm emblem with a heat lamp or gun. Do not exceed 52°C (120°F) when heating emblem.


- (3) Insert a plastic trim stick or a hard wood wedge behind the emblem to separate the adhesive backing from the body.

- (4) Clean adhesive residue from body with MOPAR Super Clean solvent or equivalent.

**INSTALLATION**

- (1) Remove protective cover from adhesive tape on back of emblem.
- (2) Position emblem properly on body (Fig. 10).

## REMOVAL AND INSTALLATION (Continued)



80b34e9b

**Fig. 10 Exterior Nameplates**

(3) Press emblem firmly to body with palm of hand.

(4) If temperature is below 21°C (70°F) warm emblem with a heat lamp or gun to assure adhesion. Do not exceed 52°C (120°F) when heating emblem.

**SIDE VIEW MIRROR****REMOVAL**


- (1) Remove door trim panel.
- (2) Disengage power mirror harness connector, if equipped.
- (3) Remove mirror flag seal.
- (4) Remove nuts attaching mirror to door (Fig. 11).
- (5) Separate mirror from door.

**INSTALLATION**

- (1) Position mirror on door. Verify that gasket seal is properly positioned.
- (2) Install nuts attaching mirror to door.
- (3) Install mirror retaining nuts.
- (4) Install mirror flag seal.
- (5) Engage power mirror harness connector, if equipped.
- (6) Install door trim panel.

**SIDE VIEW MIRROR GLASS****REMOVAL**

- (1) With damaged mirror still on vehicle, position mirror glass down and centered.
- (2) Position a wide leverage device between the bottom edge of the glass and the mirror shell.
- (3) Firmly apply pressure in an upward direction until glass assembly disengages from adapter plate.



80b46ae4

**Fig. 11 Side View Mirror**

- 1 - SIDEVIEW MIRROR  
2 - MIRROR FLAG SEAL  
3 - CONNECTOR

(4) Disconnect the heater wire terminal, if equipped, or the EC plug, if equipped.

**INSTALLATION**

- (1) Connect the heater wire terminal or the EC plug, if equipped.
- (2) Position the replacement glass in the mirror shell and align the four snap tabs with the four cavities in the shell.
- (3) Apply firm pressure inward until the replacement glass assembly engages with the adapter plate. Correct assembly will result in a firm click. Glass assembly should exhibit even gaps to the shell when complete.
- (4) Pull lightly on corners of glass assembly to ensure all four snaps are engaged and there is no free play.




REMOVAL AND INSTALLATION (Continued)

**FRONT FENDER**

**REMOVAL**


- (1) Using a wax crayon or equivalent, mark position of fender.
- (2) Remove front fender liner.
- (3) Pull back fascia and remove screws attaching fender to fascia.
- (4) Remove screws attaching lower fender bracket located behind fascia.
- (5) Remove screws attaching fender to rocker panel (Fig. 12).
- (6) Remove screws attaching rear of fender to A-pillar brackets.
- (7) Open hood.
- (8) Loosen screw under hood hinge, attaching fender to engine compartment rail.
- (9) Remove screws attaching fender to engine compartment rail (Fig. 13).
- (10) Right fender only:
  - (a) If equipped, remove radio antenna.
- (11) Separate fender from body.



80b3c70d

**Fig. 13 Upper Fender Mounting**

- 1 - FENDER
- 2 - BODY



**Fig. 12 Fender Mounting**

80b34e99

- 1 - BODY
- 2 - FENDER

## REMOVAL AND INSTALLATION (Continued)

## INSTALLATION

- (1) Position fender on body.
- (2) Right fender only:
  - (a) If equipped, install radio antenna.
- (3) Install all screws finger-tight.
- (4) Align fender with adjacent body panels and wax crayon reference marks.
- (5) Tighten all screws.
- (6) Install inner fender liner.

## FRONT DOOR TRIM PANEL

## REMOVAL

- (1) Remove trim plug from mirror flag bezel.
- (2) Remove screws attaching trim panel to door (Fig. 14).
- (3) Using trim remover (C-4829 or equivalent), detach trim panel perimeter push-in fasteners from door inner panel.
- (4) Lift trim panel upward and separate from door.
- (5) If equipped, disconnect harness connectors for power accessories.
- (6) Disconnect latch rods from inside handle actuator.
- (7) Separate trim panel from vehicle.




Fig. 14 Front Door Trim Panel

- 1 - HARNESS CONNECTOR
- 2 - NUTSERT
- 3 - TRIM PLUG
- 4 - TRIM PANEL
- 5 - PUSH-IN FASTENER
- 6 - HARNESS CONNECTOR
- 7 - LATCH RODS

## INSTALLATION


- (1) Connect latch rods to inside handle actuator.
- (2) If equipped, connect harness connectors to power accessories.
- (3) Position trim panel on door inner panel.

- (4) Press trim panel push-in fasteners inward around perimeter of door.
- (5) Install screws attaching trim panel to door.
- (6) Install trim plug in mirror flag bezel.

## FRONT DOOR WATERDAM

## REMOVAL

- (1) Remove door trim panel.
- (2) Peel the waterdam from door.
- (3) Route all harnesses and linkage rods through waterdam as necessary.
- (4) Separate waterdam from door (Fig. 15).



80b46b2f

Fig. 15 Front Door Waterdam

1 - INSULATOR PAD

## INSTALLATION


- (1) Waterdam contact surface must be free of contaminants. Clean as necessary.
- (2) Route all harnesses and linkage rods through waterdam as necessary.
- (3) Position waterdam on door and align all holes.
- (4) Press waterdam on door.
- (5) Install door trim panel.

## FRONT DOOR CHECK

## REMOVAL

- (1) Remove trim panel.
- (2) Remove waterdam.
- (3) Remove speaker.
- (4) Remove screws attaching door check to A-pillar.
- (5) Remove nuts attaching door check to door (Fig. 16).
- (6) Remove door check through speaker location hole.

REMOVAL AND INSTALLATION (Continued)



**Fig. 16 Door Check**

- 1 - DOOR CHECK
- 2 - FRONT DOOR

**INSTALLATION**

- (1) Position door check on door through speaker location hole.
- (2) Install nuts attaching door check to door.
- (3) Install screws attaching door check to A-pillar.
- (4) Install speaker.
- (5) Install waterdam.
- (6) Install trim panel.

**FRONT DOOR**

**REMOVAL**

- (1) Disconnect front door harness connector (Fig. 17).
- (2) Support door with padded floor jack.
- (3) Remove retaining clips from hinge pins.
- (4) Tap out hinge pins.
- (5) Separate door from vehicle.


**INSTALLATION**

- (1) Position door at vehicle and align hinges.
- (2) Install hinge pins.
- (3) Install retaining clips for hinge pins.
- (4) Connect front door harness connector.

**FRONT DOOR HINGE**

**REMOVAL**


- (1) Open and support door.
- (2) Using a wax pencil, or other suitable device, reference mark the hinge placement



**Fig. 17 Front Door Harness Connector**

- 1 - HARNESS CONNECTOR
- 2 - DOOR


- (3) Disconnect the door wire harness.
- (4) Remove the door check from the "A" pillar (Fig. 18).
- (5) Remove the fasteners retaining the door hinge to the door (Fig. 19).
- (6) Remove the door.
- (7) Remove the hinge from the "A" pillar.



**Fig. 18 Front Door Check**

- 1 - DOOR CHECK
- 2 - FRONT DOOR

## REMOVAL AND INSTALLATION (Continued)

**Fig. 19 Front Door Hinges**


- 1 - WASHER
- 2 - UPPER HINGE
- 3 - FRONT DOOR
- 4 - LOWER HINGE
- 5 - WASHER

**INSTALLATION**

- (1) Position hinge on "A" pillar. (Use 3M<sup>®</sup> Fast and Firm or equivalent on the hinge to body mating surface as a sealant.)
- (2) Install hinge to body bolts, but do not tighten.
- (3) Align the hinge to the reference marks and torque the bolts to 35N·m (26 ft. lbs.).
- (4) Install the door on the hinge and align with the reference marks.
- (5) Tighten the door to hinge fasteners.
- (6) For adjustment see door adjustment procedure.

**FRONT DOOR OUTSIDE HANDLE****REMOVAL**

- (1) Remove door trim panel and waterdam.
- (2) Locate glass to full up position.
- (3) Remove glass run channel.
- (4) Disconnect lock cylinder to latch rod.
- (5) Disconnect outside handle to latch rod
- (6) Remove fasteners attaching outside handle to door (Fig. 20).
- (7) Remove outside handle from door.
- (8) Disconnect anti-theft harness connector, if equipped.
- (9) Separate outside handle from vehicle.

**Fig. 20 Front Door Outside Handle**

- 1 - DOOR
- 2 - OUTSIDE HANDLE

**INSTALLATION**

- (1) Position outside handle at door.
- (2) Connect anti-theft harness connector, if equipped.
- (3) Position outside handle in door.
- (4) Install fasteners attaching outside handle to door.
- (5) Connect outside handle to latch rod
- (6) Connect lock cylinder to latch rod.
- (7) Install glass run channel.
- (8) Locate glass to full down position.
- (9) Install waterdam and door trim panel.


**FRONT DOOR LOCK CYLINDER****REMOVAL**

- (1) Remove door trim panel and insulator.
- (2) Remove outside door handle.
- (3) Remove screw securing lock cylinder retainer to outside door handle (Fig. 21).
- (4) Separate lock cylinder from door handle.
- (5) Disconnect lock cylinder switch, if equipped.

**INSTALLATION**


- (1) Connect lock cylinder switch, if equipped.
- (2) Position lock cylinder in door handle.
- (3) Position lock cylinder retainer and install screw.
- (4) Install outside door handle.
- (5) Install insulator and trim panel.

REMOVAL AND INSTALLATION (Continued)



**Fig. 21 Front Door Lock Cylinder**

- 1 - OUTSIDE DOOR HANDLE
- 2 - LOCK CYLINDER
- 3 - ANTI-THEFT SWITCH
- 4 - RETAINER



**Fig. 22 Door Latch**

- 1 - DOOR
- 2 - LATCH
- 3 - ISOLATOR

**LOCK CYLINDERS**

Ignition, door, deck lid, and rear hatch lock cylinders are all codable to the key. Lock barrels, tumblers, and tumbler springs are available to allow the technician to change replacement locks cylinders to match the customer's original key set. See the appropriate section in this manual for lock cylinder removal. See the Mopar® catalogue for part numbers and lock coding procedures.

**FRONT DOOR LATCH**

**REMOVAL**

- (1) Locate glass in full up position.
- (2) Remove door trim panel and isolator.
- (3) Remove glass run channel.
- (4) Remove screws attaching door latch to door (Fig. 22).
- (5) Disconnect all rods from door latch.
- (6) Disconnect wire harness connector, if equipped.
- (7) Separate door latch from door.


**INSTALLATION**

- (1) Position door latch at door.
- (2) Connect wire harness connector, if equipped.
- (3) Connect all rods to door latch.
- (4) Install screws attaching door latch to door. Tighten screws to 10 N·m (7 ft. lbs.) torque.
- (5) Install glass run channel.
- (6) Install isolator and door trim panel.

**FRONT DOOR LATCH STRIKER**

**REMOVAL**

- (1) Remove screws attaching striker to B-pillar.
- (2) Separate striker and spacer from B-pillar (Fig. 23).



**Fig. 23 Front Door Latch Striker**

- 1 - B-PILLAR
- 2 - SPACER
- 3 - STRIKER

**INSTALLATION**

- (1) Position striker and spacer on B-pillar.


## REMOVAL AND INSTALLATION (Continued)

(2) Install screws attaching striker to B-pillar. Tighten screws to 28 N·m (20 ft. lbs.) torque.

## FRONT DOOR INSIDE HANDLE ACTUATOR

## REMOVAL

- (1) Remove door trim panel.
- (2) Disconnect latch and lock rods from inside handle actuator.
- (3) Remove screws attaching inside handle actuator to trim panel (Fig. 24).
- (4) Separate inside handle actuator from trim panel.



**Fig. 24 Front Door Inside Handle Actuator**

- 1 - INSIDE HANDLE ACTUATOR
- 2 - DRIVER'S DOOR TRIM PANEL
- 3 - SCREW

## INSTALLATION

- (1) Position inside handle actuator in trim panel.
- (2) Install screws attaching inside handle actuator to trim panel.
- (3) Connect latch and lock rods to inside handle actuator.
- (4) Install door trim panel.


## FRONT DOOR INNER BELT SEAL

## REMOVAL

- (1) Remove door trim panel.
- (2) Using a trim stick or other suitable device, carefully pry up inner edge of seal (Fig. 25).
- (3) Grasp the edge of the seal and pull upward to remove seal from door flange.

## INSTALLATION

- (1) Position the seal on the door flange.
- (2) Firmly press downward to seat seal on the door flange.



**Fig. 25 Inner/Outer Belt Weather Strip**

- 1 - INNER BELT WEATHERSTRIP
- 2 - OUTER BELT WEATHERSTRIP

- (3) Install the door trim panel.

## FRONT DOOR OUTER BELT SEAL

## REMOVAL

- (1) Lower the door glass.
- (2) Remove the screw from the inner door panel attaching the seal to outer door panel (Fig. 25).
- (3) Pull the seal rearward to release from the side view mirror bezel.
- (4) Lift seal and separate from door panel.

## INSTALLATION

- (1) Position seal on the door panel.
- (2) Push the seal forward to install under the side view mirror bezel.
- (3) Install the screw from the inner door panel attaching the seal to outer door panel.
- (4) Raise the door glass.

## FRONT DOOR GLASS RUN CHANNEL WEATHERSTRIP



## REMOVAL

- (1) Remove trim panel.
- (2) Remove inner belt weatherstrip.
- (3) Remove outer belt weatherstrip.
- (4) Grasp seal from upper run channel corner and firmly pull weatherstrip from flange and run channel (Fig. 26).

## INSTALLATION

**NOTE:** Soapy water may be used to aid in installation.

REMOVAL AND INSTALLATION (Continued)



**Fig. 26 Front Door Glass Run Channel Weatherstrip**

- 1 - GLASS RUN CHANNEL WEATHERSTRIP
- 2 - DOOR

**Fig. 27 Front Door Glass Run Channel**

- 1 - DOOR
- 2 - GLASS
- 3 - GLASS RUN CHANNEL
- 4 - REGULATOR

- (1) Remove front door speaker.
- (2) Position weatherstrip on flange aligning each corner.
- (3) Press weatherstrip into position.
- (4) Carefully move door glass for and aft and press weatherstrip into glass run channels.
- (5) Install front door speaker.
- (6) Install outer belt weatherstrip.
- (7) Install inner belt weatherstrip.
- (8) Install trim panel.

- (5) Install inner and outer belt weatherstrip.
- (6) Install isolator.
- (7) Install door trim panel.

**FRONT DOOR GLASS RUN CHANNEL**

**FRONT DOOR OPENING WEATHERSTRIP**

**REMOVAL**

**REMOVAL**

**NOTE: Only the rearward glass run channel is serviceable.**

- (1) Remove door trim panel.
- (2) Remove isolator.
- (3) Remove inner and outer belt weatherstrip.
- (4) Remove bolt attaching run channel to inner door panel (Fig. 27).
- (5) Peel back glass run channel weatherstrip on rear run channel.
- (6) Pull glass run channel downward to separate from door.
- (7) Remove glass run channel from door.

**INSTALLATION**

**INSTALLATION**

- (1) Position glass run channel in door.
- (2) Align glass run channel with door frame run channel and slide channel upward to secure door.
- (3) Press glass run channel weatherstrip into rear run channel.
- (4) Install bolt attaching run channel to inner door panel.

- (1) Position weatherstrip at corners.
- (2) Move upward and around edge of door opening seating weatherstrip onto flange (Fig. 28).
- (3) Engage connector plug with each end of weatherstrip at bottom of door opening.
- (4) Install B-pillar lower trim.
- (5) Install B-pillar upper trim.
- (6) Install A-pillar trim.


**FRONT DOOR SECONDARY WEATHERSTRIP**

**REMOVAL**


The front door secondary weatherstrip is attached to the door shutface with push-in fasteners.

- (1) Open door.
- (2) Using a trim panel removal tool, remove push-in fasteners attaching secondary weatherstrip to door shutface (Fig. 29).
- (3) Separate secondary weatherstrip from door.

## REMOVAL AND INSTALLATION (Continued)

**Fig. 28 Door Opening Weatherstrip**

- 1 - REAR DOOR OPENING WEATHERSTRIP  
2 - FRONT DOOR OPENING WEATHERSTRIP

**Fig. 29 Front Door Secondary Weatherstrip**


- 1 - SECONDARY WEATHERSTRIP

**INSTALLATION**

- (1) Clean contact area as necessary.
- (2) Position secondary weatherstrip on door shutface.
- (3) Install push-in fasteners attaching secondary weatherstrip to door shutface.

**FRONT DOOR WINDOW REGULATOR****REMOVAL**

- (1) Remove door trim panel.
- (2) Remove isolator.
- (3) Remove front door glass.
- (4) Loosen bolts attaching regulator to inner door panel (Fig. 30).
- (5) Remove bolt attaching regulator to inner door panel (Fig. 31).
- (6) Lift regulator upward to disengage bolts from door inner panel.
- (7) Disengage power window regulator harness connector, if equipped.
- (8) Remove regulator through access hole in door.

**Fig. 30 Front Door Regulator Bolts**

- 1 - FRONT DOOR  
2 - REMOVE BOLT  
3 - LOOSEN BOLTS

**INSTALLATION**


- (1) Position regulator in door through access hole.
- (2) Engage power window regulator harness connector, if equipped.
- (3) Lift regulator upward and engage bolts in door inner panel key hole slots.
- (4) Install bolt attaching regulator to inner door panel.
- (5) Tighten bolts attaching regulator to inner door panel.
- (6) Install front door glass.
- (7) Install isolator.
- (8) Install door trim panel.

**FRONT DOOR GLASS****REMOVAL**

- (1) Locate glass to full down position.
- (2) Remove trim panel.




REMOVAL AND INSTALLATION (Continued)



**Fig. 31 Front Door Window Regulator**


- 1 - FRONT DOOR
- 2 - REGULATOR

- (3) Remove inner belt weatherstrip.
- (4) Remove outer belt weatherstrip.
- (5) Locate glass to 3/4 up position.
- (6) Remove front door insulator.
- (7) Using a long flat blade or hook type tool, disengage clips (Fig. 32) attaching glass retainer to glass lift plate.
- (8) Carefully push bottom of glass panel outward to disengage glass retainer studs from lift plate (Fig. 33).
- (9) Lift glass upward and out of door.



**Fig. 32 Front Door Glass Clips**

- 1 - GLASS
- 2 - RETAINER
- 3 - CLIP
- 4 - LIFT PLATE
- 5 - REGULATOR
- 6 - CLIP



**Fig. 33 Front Door Glass Retainer Studs**

- 1 - GLASS
- 2 - RETAINER
- 3 - LIFT PLATE
- 4 - STUD

**INSTALLATION**

- (1) Lower glass into position.
- (2) Carefully align glass retainer studs with lift plate and insert studs into lift plate.
- (3) Engage clips attaching glass retainer to glass lift plate.
- (4) Install front door insulator.
- (5) Locate glass to full down position.
- (6) Install outer belt weatherstrip.
- (7) Install inner belt weatherstrip.
- (8) Install trim panel.

**REAR DOOR B-PILLAR SEAL**

**REMOVAL**

- The B-pillar seal is attached to the rear door with adhesive tape.
- (1) Peel seal from the door (Fig. 34).

**INSTALLATION**


- (1) Clean contact area with Mopar Super Kleen or equivalent.
- (2) Remove carrier from seal.
- (3) Align seal on door and press into place.

**REAR DOOR TRIM PANEL**

**REMOVAL**

- (1) Remove screws attaching trim panel to door (Fig. 35).
- (2) Using trim remover (C-4829 or equivalent), detach trim panel perimeter push-in fasteners from door inner panel.
- (3) Lift trim panel upward and separate from door.

## REMOVAL AND INSTALLATION (Continued)



80b46b1e


**Fig. 34 B-Pillar Seal**

1 - B-PILLAR SEAL

(4) If equipped, disconnect harness connectors for power accessories.

(5) Disconnect latch rods from inside handle actuator.

(6) Separate trim panel from vehicle.



80b5cb4a

**Fig. 35 Rear Door Trim Panel**

1 - TRIM PANEL  
2 - NUTSERT  
3 - HARNESS CONNECTOR  
4 - LATCH RODS

**INSTALLATION**

(1) Connect latch rods to inside handle actuator.

(2) If equipped, connect harness connectors to power accessories.

(3) Position trim panel on door inner panel.

(4) Press trim panel push-in fasteners inward around perimeter of door.

(5) Install screws attaching trim panel to door.


**REAR DOOR WATERDAM****REMOVAL**

(1) Remove door trim panel.

(2) Peel the waterdam from door.

(3) Route all harnesses and linkage rods through waterdam as necessary.

(4) Separate waterdam from door (Fig. 36).



80b46b0f

**Fig. 36 Rear Door Waterdam**

1 - INSULATOR PAD

**INSTALLATION**

(1) Waterdam contact surface must be free of contaminants. Clean as necessary.

(2) Route all harnesses and linkage rods through waterdam as necessary.

(3) Position waterdam on door and align all holes.

(4) Press waterdam on door.

(5) Install door trim panel.

**REAR DOOR CHECK****REMOVAL**

(1) Remove trim panel.

(2) Remove waterdam.

(3) Remove speaker.

(4) Remove screws attaching door check to B-pillar.

(5) Remove nuts attaching door check to door (Fig. 37).

(6) Remove door check through speaker location hole.

**INSTALLATION**

(1) Position door check on door through speaker location hole.


(2) Install nuts attaching door check to door.

(3) Install screws attaching door check to B-pillar.

(4) Install speaker.

(5) Install waterdam.

REMOVAL AND INSTALLATION (Continued)



**Fig. 37 Door Check**


- 1 - DOOR CHECK
- 2 - REAR DOOR

(6) Install trim panel.

**REAR DOOR**

**REMOVAL**

- (1) Disconnect rear door harness connector (Fig. 38).
- (2) Support door with padded floor jack.
- (3) Remove retaining clips from hinge pins.
- (4) Tap out hinge pins.
- (5) Separate door from vehicle.



**Fig. 38 Rear Door Harness Connector**

- 1 - HARNESS CONNECTOR


**INSTALLATION**

- (1) Position door at vehicle and align hinges.
- (2) Install hinge pins.
- (3) Install retaining clips for hinge pins.
- (4) Connect rear door harness connector.

**REAR DOOR HINGE**

**REMOVAL**

- (1) Open front door and rear door.
- (2) Reference mark hinges for installation (Fig. 39).
- (3) Support rear door for removal of hinges.
- (4) Remove B pillar trim.
- (5) Remove nuts holding door to hinge.
- (6) Remove door.
- (7) Remove bolts holding hinge to B pillar.



**Fig. 39 Rear Door Hinge**

- 1 - UPPER HINGE
- 2 - WASHER
- 3 - WASHER
- 4 - LOWER HINGE
- 5 - REAR DOOR

**INSTALLATION**

- (1) Install hinge on B pillar and align reference marks.
- (2) Install bolts holding hinge to B pillar. Tighten bolts to 35N·m (23 ft. lbs.).
- (3) Install door on hinge and align reference marks. Install bolts and tighten to 35N·m (26 ft. lbs.).
- (4) Check door for fit and ease of operation. Adjust as necessary. See adjustment section.

## REMOVAL AND INSTALLATION (Continued)

- (5) Install B pillar trim.

## REAR DOOR OUTSIDE HANDLE

## REMOVAL

- (1) Remove door trim panel and waterdam.
- (2) Locate glass to full up position.
- (3) Disconnect lock knob to latch rod.
- (4) Disconnect outside handle to latch rod.
- (5) Remove fasteners attaching outside handle to door (Fig. 40).
- (6) Remove outside handle from door.
- (7) Separate outside handle from vehicle.




Fig. 40 Front Door Outside Handle

- 1 - DOOR
- 2 - OUTSIDE HANDLE

## INSTALLATION

- (1) Position outside handle at door.
- (2) Position outside handle in door.
- (3) Install fasteners attaching outside handle to door.
- (4) Connect outside handle to latch rod.
- (5) Connect lock knob to latch rod.
- (6) Locate glass to full down position.
- (7) Install waterdam and door trim panel.

## REAR DOOR LATCH

## REMOVAL

- (1) Remove door trim panel and waterdam.
- (2) Remove screws attaching latch to door (Fig. 41).
- (3) Disconnect rods from door latch.

- (4) Separate door latch from door.




Fig. 41 Rear Door Latch

- 1 - DOOR
- 2 - LATCH
- 3 - OUTSIDE HANDLE

## INSTALLATION

- (1) position latch in door.
- (2) Connect rods to door latch.
- (3) Install screws attaching latch to door. Tighten screws to 10 N·m (95 in. lbs.) torque.
- (4) Install waterdam and door trim panel.

## REAR DOOR LATCH STRIKER

## REMOVAL

- (1) Open door.
- (2) Remove screws attaching striker to C-pillar (Fig. 42).
- (3) Separate striker and spacer from vehicle.

## INSTALLATION


- (1) Position striker and spacer on C-pillar.
- (2) Install screws. Tighten to 28 N·m (250 in. lbs.) torque.

## REAR DOOR INSIDE HANDLE ACTUATOR

## REMOVAL

- (1) Remove door trim panel.
- (2) Disconnect latch and lock rods from inside handle actuator.
- (3) Remove screws attaching inside handle actuator to trim panel (Fig. 43).


REMOVAL AND INSTALLATION (Continued)



**Fig. 42 Rear Door Latch Striker**

- 1 - TAPPING PLATE
- 2 - SPACER
- 3 - STRIKER

(4) Separate inside handle actuator from trim panel.



**Fig. 43 Rear Door Inside Handle Actuator**

- 1 - REAR DOOR TRIM PANEL
- 2 - SCREW
- 3 - INSIDE HANDLE ACTUATOR


**INSTALLATION**

- (1) Position inside handle actuator in trim panel.
- (2) Install screws attaching inside handle actuator to trim panel.
- (3) Connect latch and lock rods to inside handle actuator.
- (4) Install door trim panel.

**REAR DOOR INNER BELT WEATHERSTRIP**

**REMOVAL**

- (1) Remove door trim panel.
- (2) Using a trim stick, carefully pry rear inner edge of inner belt weatherstrip upward.
- (3) Grasp weatherstrip and pull upward to separate from door flange (Fig. 44).



**Fig. 44 Rear Door Inner/Outer Belt Weatherstrip**

- 1 - INNER BELT WEATHERSTRIP
- 2 - OUTER BELT WEATHERSTRIP

**INSTALLATION**

- (1) Position weatherstrip on door flange.
- (2) Firmly press downward to seat weatherstrip on flange.
- (3) Install trim panel.

**REAR DOOR OUTER BELT WEATHERSTRIP**

**REMOVAL**

- (1) Remove trim panel.
- (2) Using a small flat blade, disengage tangs attaching outer belt weatherstrip to inner door panel.
- (3) Lift weatherstrip upward and separate from door (Fig. 44).

**INSTALLATION**

- (1) Position the weatherstrip onto the door flange.
- (2) Force the weatherstrip onto door flange and engage tangs. Continue rearward until it is seated on flange.
- (3) Instal trim panel.

**REAR DOOR OPENING WEATHERSTRIP**

**REMOVAL**

- (1) Remove C-pillar trim.
- (2) Remove B-pillar upper trim.

## REMOVAL AND INSTALLATION (Continued)

- (3) Remove B-pillar lower trim.
- (4) Remove screws at front of quarter trim panel.
- (5) Pull weatherstrip from door opening flange.

## INSTALLATION


- (1) Position weatherstrip at corners.
- (2) Move upward and around edge of door opening seating weatherstrip onto flange (Fig. 28).
- (3) Engage connector plug with each end of weatherstrip at bottom of door opening.
- (4) Install screws at front of quarter trim panel.
- (5) Install B-pillar lower trim.
- (6) Install B-pillar upper trim.
- (7) Install C-pillar trim.

## REAR DOOR SECONDARY WEATHERSTRIP

## REMOVAL

The rear door secondary weatherstrip is attached to the door shutface with push-in fasteners.

- (1) Open door.
- (2) Using a trim panel removal tool, remove push-in fasteners attaching secondary weatherstrip to door shutface.
- (3) Separate secondary weatherstrip from door (Fig. 45).



80b46b1b

**Fig. 45 Rear Door Secondary Weatherstrip**

1 - SECONDARY WEATHERSTRIP


## INSTALLATION

- (1) Clean contact area as necessary.
- (2) Position secondary weatherstrip on door shutface.
- (3) Install push-in fasteners attaching secondary weatherstrip to door shutface.

## REAR DOOR WINDOW REGULATOR

## REMOVAL

- (1) Remove door trim panel and waterdam. Disconnect the speaker harness and power window harness, if equipped. If necessary, refer to removal procedure.
- (2) Lower window glass.
- (3) Pull run weatherstrip from fixed glass.
- (4) Remove fasteners retaining fixed glass module.
- (5) Remove the fixed glass module.
- (6) Raise the door glass and support.
- (7) Remove the window clips retaining regulator (Fig. 46).
- (8) Remove the door glass.
- (9) Remove the fasteners retaining the regulator (Fig. 47).
- (10) Remove the regulator.



80b4fb30


**Fig. 46 Window Regulator Retainer Clips**

- 1 - GLASS
- 2 - RETAINER
- 3 - CLIP
- 4 - LIFT PLATE
- 5 - REGULATOR
- 6 - CLIP

## INSTALLATION

- (1) Position the window regulator in the door.
- (2) Install the fasteners retaining the regulator.
- (3) Install the door glass.
- (4) Install the window clips retaining regulator.
- (5) Lower the door glass.
- (6) Install the fixed glass module. Tighten the fasteners.
- (7) Install the run weatherstrip.
- (8) Install the waterdam, door panel, and connect the power window and speaker harness if equipped.
- (9) Cycle the glass and check for proper operation.


REMOVAL AND INSTALLATION (Continued)



80b3c6f8

**Fig. 47 Rear Door Window Regulator**

- 1 - DOOR
- 2 - REGULATOR



80b46b1f

**Fig. 48 Glass Channel**

- 1 - GLASS
- 2 - REGULATOR

**REAR DOOR WINDOW GLASS**

**REMOVAL**

- (1) Lower window glass.
- (2) Remove trim panel.
- (3) Remove waterdam.
- (4) Remove inner belt weatherstrip.
- (5) Remove stationary glass.
- (6) Disengage clips attaching window glass to lift plate.
- (7) Press studs out of lift plate.
- (8) Lift window glass from door (Fig. 48).

**INSTALLATION**


- (1) Position window glass in door.
- (2) Engage studs into lift plate.
- (3) Engage clips attaching window glass to lift plate.
- (4) Install stationary glass.
- (5) Install inner belt weatherstrip.
- (6) Install waterdam.
- (7) Install trim panel.

**REAR DOOR STATIONARY GLASS**

**REMOVAL**

- (1) Remove door trim panel.
- (2) Remove waterdam.
- (3) Remove inner belt weatherstrip.

- (4) Remove bolt attaching bottom of rear glass run channel to door.
- (5) Pull run channel downward and separate from door.
- (6) Remove screws attaching stationary door glass frame to door (Fig. 49) and (Fig. 50).
- (7) Separate stationary door glass from door.



80b46b2c


**Fig. 49 Stationary Door Glass**

- 1 - DOOR
- 2 - STATIONARY DOOR GLASS

**INSTALLATION**

- (1) Position stationary door glass in door.
- (2) Install screws attaching stationary door glass frame to door.
- (3) Install glass run channel.
- (4) Install inner belt weatherstrip.
- (5) Install waterdam.
- (6) Install door trim panel.

## REMOVAL AND INSTALLATION (Continued)



80b46b2b

**Fig. 50 Stationary Door Glass**

- 1 - STATIONARY DOOR GLASS  
2 - DOOR

## ROOF RAIL WEATHERSTRIP W/RETAINER

## REMOVAL

- (1) Open front and rear doors.
- (2) Remove secondary seal from retainer to access the screws holding the retainer to the A pillar and roof panel.
- (3) Remove the screws holding the retainer in place (Fig. 51).
- (4) Remove the retainer.

## INSTALLATION

- (1) Position the retainer on the A pillar and roof panel.
- (2) Align the screw holes and install the screws.
- (3) Install secondary seal.

## FUEL FILL DOOR

## REMOVAL

- (1) Open the fuel filler door.
- (2) Remove the screws attaching the door to the quarter panel (Fig. 52).
- (3) Remove the door from the panel.


## INSTALLATION

- (1) Position the fuel filler door on the quarter panel with the screw holes aligned.
- (2) Install the screws attaching the fuel filler door to the quarter panel.

## BODY SIDE CLADDING

## REMOVAL-FENDER/QUARTER PANEL


- (1) Remove the screws at wheel opening (Fig. 53).



80b46b4a

**Fig. 51 Upper Body Seal With Retainer**

- 1 - ROOF RAIL WEATHERSTRIP  
2 - RETAINER  
3 - SCREW  
4 - BLOCKER



80b46ae3

**Fig. 52 Fuel Filler Door**

- 1 - FUEL FILL DOOR


- (2) Using a trim stick, gently pry bottom of cladding up.
- (3) Lift upwards and remove cladding.

## INSTALLATION-FENDER/QUARTER PANEL

- (1) Thoroughly clean the area with Mopar Super Kleen or equivalent.
- (2) Align the cladding with the screw holes in the fender.
- (3) Press the cladding in place.
- (4) Install the screws at the wheel opening.



REMOVAL AND INSTALLATION (Continued)




80b46b61

**Fig. 53 Front Fender/ Quarter Panel**

- 1 - SCREW
- 2 - QUARTER PANEL CLADDING
- 3 - FRONT FENDER CLADDING
- 4 - SCREW

**REMOVAL-REAR DOOR**

- (1) Open the rear door.
- (2) Using a trim stick, pry the upper rear edge off the door. Continue towards the front edge of the rear door (Fig. 54).
- (3) Using a heat gun, warm the adhesive tape on the bottom of the cladding and remove the cladding.



80b46b5f

**Fig. 54 Rear Door Cladding**


- 1 - CLADDING

**INSTALLATION-REAR DOOR**

- (1) Clean the area thoroughly with Mopar Super Kleen, or equivalent.
- (2) Align the body side cladding with the slots in the door. Press the adhesive pad to the door and snap the retainers into the slots.

**REMOVAL-FRONT DOOR**

- (1) Open the front door.
- (2) Using a trim stick, pry the upper rear edge off the door. Continue to the front edge of the front door (Fig. 55).
- (3) Using a heat gun, warm the adhesive tape on the lower edge of the cladding and pull the cladding from the door.



80b46b60

**Fig. 55 Front Door Cladding**

- 1 - CLADDING

**INSTALLATION-FRONT DOOR**


- (1) Clean the area thoroughly with Mopar Super Kleen, or equivalent.
- (2) Align the body side cladding with the slots in the door. Press the adhesive pad to the door and snap the retainers into the slots.

**SILL MOLDING**

**REMOVAL**

- The sill trim molding is held in place with molded in snap retainers (Fig. 56).
- (1) Using a trim stick or other suitable device, carefully pry up one corner of the sill trim.

## REMOVAL AND INSTALLATION (Continued)



80b34ee7

**Fig. 56 Sill Trim Molding**

- |                         |                   |
|-------------------------|-------------------|
| 1 - B-PILLAR UPPER TRIM | 6 - CLIP          |
| 2 - ACCESS COVER        | 7 - SCUFF PLATE   |
| 3 - B-PILLAR LOWER TRIM | 8 - SILL TRIM     |
| 4 - PLASTIC NUT         | 9 - A-PILLAR TRIM |
| 5 - COWL LOWER TRIM     |                   |

(2) Grasp the edge of the trim and pull up gently to release the snap retainers.

**INSTALLATION**

- (1) Position the sill molding on the door sill.
- (2) Press the snap retainers into place.

**A-PILLAR TRIM****REMOVAL**

The A-pillar trim is attached to the A-pillar with spring clips.

- (1) Grasp A-pillar trim and pull trim outward from A-pillar (Fig. 57).
- (2) Separate A-pillar trim from A-pillar.


**INSTALLATION**

- (1) Position A-pillar trim on A-pillar and, starting at the bottom, press into place.
- (2) Using a trim stick or other suitable tool, carefully cover the edge of the trim with weatherstrip.

**COWL LOWER TRIM****REMOVAL**


- (1) Remove front door sill trim.
- (2) Remove screws attaching cowl trim to floor.
- (3) Remove plastic nut.
- (4) Grasp cowl trim and pull outward to separate from clip.
- (5) Separate cowl trim from vehicle.

REMOVAL AND INSTALLATION (Continued)



**Fig. 57 A-Pillar Trim**

- 1 - A-PILLAR TRIM
- 2 - A-PILLAR
- 3 - SPRING CLIP



**Fig. 58 Door Sill Scuff Plates**

- 1 - B-PILLAR
- 2 - FRONT DOOR SCUFF PLATE
- 3 - REAR DOOR SCUFF PLATE

**INSTALLATION**

- (1) Position cowl trim and press into place.
- (2) Install screws attaching cowl trim to floor.
- (3) Install plastic nut.
- (4) Install front door sill trim.

**OVERHEAD ASSIST HANDLE**

**REMOVAL**

- (1) Remove the screws holding the assist handle to the roof panel.
- (2) Remove the assist handle from the roof panel.

**INSTALLATION**

- (1) Align the assist handle with the screw holes in the roof panel.
- (2) Install the screws holding the assist handle to the roof panel.

**FRONT DOOR SCUFF PLATE**

**REMOVAL**

- (1) Using a trim stick or other suitable tool, carefully pry up the scuff plate from the door sill (Fig. 58).
- (2) Remove the scuff plate.

**INSTALLATION**

- (1) Install the scuff plate on the door sill.
- (2) Press the molded in snap retainers into the door sill.

**B-PILLAR UPPER TRIM**

**REMOVAL**

- (1) Remove shoulder belt height adjustment knob.
- (2) Remove front seat belt turning loop.
- (3) Remove the screw attaching lower B pillar trim.
- (4) Pull lower B pillar trim out far enough to remove upper trim panel.
- (5) Grasp upper B-pillar trim and pull outward to detach from B-pillar (Fig. 59).

**INSTALLATION**

- (1) Position trim panel on B-pillar.
- (2) Ensure trim panel covers inner edge of door opening weatherstrip and press inward to seat.
- (3) Install screw attaching lower B pillar trim panel.
- (4) Install front seat belt turning loop.
- (5) Install shoulder belt height adjustment knob.

**B-PILLAR LOWER TRIM**

**REMOVAL**

- (1) Remove front door sill trim.
- (2) Remove front seat shoulder belt anchor bolt.
- (3) Remove front seat shoulder belt height adjustment knob and turning loop.
- (4) Remove screw attaching front of quarter panel trim to floor.

## REMOVAL AND INSTALLATION (Continued)

(5) Remove screws attaching front and rear of B-pillar lower trim to floor.

(6) Remove screw attaching B-pillar lower trim to B-pillar (Fig. 59).

(7) Grasp B-pillar lower trim and pull outward to separate from B-pillar.

(8) Route seat/shoulder belt through access slot in B-pillar lower trim.

(9) Separate B-pillar lower trim from B-pillar.

## INSTALLATION

(1) Position B-pillar lower trim panel at B-pillar.

(2) Route seat/shoulder belt through access slot in B-pillar lower trim.

(3) Press B-pillar lower trim onto B-pillar.

(4) Install screw attaching B-pillar lower trim to B-pillar.

(5) Install screw attaching front of B-pillar lower trim to floor.

(6) Install screw attaching front of quarter panel trim to floor.

(7) Install front seat shoulder belt anchor bolt.

(8) Install front seat shoulder belt height adjustment knob and turning loop.


(9) Install front door sill trim.

## REAR DOOR SCUFF PLATE

## REMOVAL

(1) The rear door scuff plate is attached with molded-in snap retainers.

(2) Using a trim stick or other suitable tool, carefully pry the scuff plate from the sill (Fig. 58).



80b34ee7

**Fig. 59 B-Pillar Trim Panel**

- 1 - B-PILLAR UPPER TRIM
- 2 - ACCESS COVER
- 3 - B-PILLAR LOWER TRIM
- 4 - PLASTIC NUT
- 5 - COWL LOWER TRIM

- 6 - CLIP
- 7 - SCUFF PLATE
- 8 - SILL TRIM
- 9 - A-PILLAR TRIM

REMOVAL AND INSTALLATION (Continued)

**INSTALLATION**

- (1) Position the scuff plate on the sill and snap into place.

**C-PILLAR UPPER TRIM**

**REMOVAL**

- (1) Remove rear shoulder belt turning loop.
- (2) Remove rear shoulder belt height adjustment knob.
- (3) Remove screws attaching quarter panel trim.
- (4) Pull quarter panel trim outward as necessary.
- (5) Grasp C-pillar upper trim and pull outward to disengage from C-pillar (Fig. 60).
- (6) Route rear shoulder belt through access hole.
- (7) Separate C-pillar upper trim from vehicle.


**INSTALLATION**

- (1) Position C-pillar upper trim at C-pillar.
- (2) Route rear shoulder belt through access hole.
- (3) Press C-pillar upper trim onto C-pillar.
- (4) Press quarter panel trim into place as necessary.
- (5) Ensure front edge of trim is covered by weatherstrip.
- (6) Install screws attaching quarter panel trim.
- (7) Install rear shoulder belt height adjustment knob.
- (8) Install rear shoulder belt turning loop.

**QUARTER PANEL TRIM**

**REMOVAL**

- (1) Move rear seat to cargo position.
- (2) If equipped, remove sunshade cover.



80b46c7f

**Fig. 60 Right Side Trim Panel**

- |                        |                         |
|------------------------|-------------------------|
| 1 - D-PILLAR TRIM      | 6 - STORAGE BIN         |
| 2 - SNAP-IN NUT        | 7 - BRACKET             |
| 3 - BRACKET            | 8 - B-PILLAR LOWER TRIM |
| 4 - SNAP-IN NUT        | 9 - C-PILLAR UPPER TRIM |
| 5 - QUARTER TRIM PANEL | 10 - SNAP-IN NUT        |

## REMOVAL AND INSTALLATION (Continued)

- (3) Open liftgate.
- (4) Remove upper and lower liftgate opening trim panels.
- (5) Remove D-pillar upper trim.
- (6) Remove storage bin (right side only).
- (7) Remove C-pillar upper trim panel.
- (8) Remove mounting screws.
- (9) Pull quarter trim panel forward and disengage connectors for CD player and power outlet, if equipped.
- (10) Pull quarter trim panel extension in the rear door opening upward.
- (11) Remove rear quarter trim panel.

## INSTALLATION

- (1) Position quarter trim panel, engage connectors for CD player and power outlet, if equipped, and align screw holes.
- (2) Install quarter trim panel.
- (3) Install C-pillar upper trim panel.
- (4) Install storage bin.
- (5) Install D-pillar upper trim panel.
- (6) Install upper and lower liftgate opening trim panels.
- (7) If equipped, install sunshade cover.
- (8) Install cargo loops.
- (9) Move the rear seat to the upright position.

## STORAGE BIN

## REMOVAL

- (1) Open the storage bin lid and remove screws on each side of the lid hinge.
- (2) Pull upward sharply on the bottom of the bin to disengage hooks.
- (3) Raise bin and move inboard to disengage the quarter trim panel.


## INSTALLATION

- (1) Position the bin hooks high in the slots on the quarter trim panel.
- (2) Push downward until the bin snaps into place.
- (3) Install the hinge screws.

## UPPER LIFTGATE OPENING TRIM

## REMOVAL


- (1) The upper liftgate opening trim is held on with spring clips.
- (2) Grasp the rear of the trim piece and pull down and back to disengage clips (Fig. 61).
- (3) Slide the trim piece to the rear to disengage headliner locating hooks.



80bdbce8

**Fig. 61 Upper Liftgate Opening Trim**

1 - UPPER LIFTGATE OPENING TRIM



80bdbce9

**Fig. 62 Headliner Locating Hooks**

1 - UPPER LIFTGATE OPENING TRIM

2 - HEADLINER

## INSTALLATION


- (1) The liftgate upper opening trim piece is equipped with headliner locating hooks (Fig. 62).
- (2) Align the locating hooks with the slots in the headliner.
- (3) Engage the spring clips and press the liftgate upper opening trim panel into place.

## D-PILLAR TRIM

## REMOVAL

- The D-pillar trim is attached to the D-pillar with spring clips (Fig. 63).
- (1) Remove liftgate opening upper trim panel. Consult the appropriate procedure in this section.
  - (2) Grasp D-pillar trim and pull outward from D-pillar.
  - (3) Separate D-pillar trim from D-pillar.

## REMOVAL AND INSTALLATION (Continued)

**Fig. 63 D Pillar Upper Trim**

1 - D PILLAR UPPER TRIM

**INSTALLATION**

- (1) Position D-pillar trim panel at D-pillar and press into place.
- (2) Install upper liftgate opening trim panel.

**FRONT SHOULDER BELT****REMOVAL**

- (1) Move the seat to the fully forward position.
- (2) Unsnap turning loop cover.
- (3) Remove upper anchor bolt.
- (4) Remove the B pillar trim.
- (5) Remove the bolt attaching the retractor to the B pillar.
- (6) Remove the bolt attaching the belt anchor to the B pillar.
- (7) Disengage retractor wire harness.
- (8) Remove the belt and retractor assembly.

**INSTALLATION**

- (1) Position the belt and retractor assembly on the B pillar.
- (2) Install the bolt attaching the belt anchor to the B pillar.
- (3) Install the bolt attaching the retractor to the B pillar.
- (4) Tighten the anchor bolts to 37N·m (27ft. lbs.).
- (5) Install the B pillar trim.
- (6) Install the upper anchor bolt. Tighten the anchor bolt to 37N·m (27ft. lbs.).
- (7) Close the turning loop cover.

**FRONT SHOULDER BELT BUCKLE****REMOVAL**

- (1) Move the seat to the fully forward position.

- (2) Remove the bolt holding the seat belt buckle to the floor.
- (3) Separate the seat belt buckle from the vehicle.

**INSTALLATION**

- (1) Position the seat belt buckle on the floor and install the bolt.
- (2) Tighten the anchor bolt to 37N·m (27 ft. lbs.).

**REAR SEAT SHOULDER BELT****REMOVAL**

- (1) Move lower seat to cargo position.
- (2) Remove lower seat/shoulder belt attaching bolt (Fig. 64).
- (3) Move seat back to cargo position.
- (4) Remove seat/shoulder belt upper turning loop
- (5) Remove C and D pillar trim. See appropriate procedures in this section.
- (6) Remove seat/shoulder belt reel attaching bolt.
- (7) Remove seat/shoulder belt assembly.

**INSTALLATION**

- (1) Position seat/shoulder belt reel assembly using locating pin (Fig. 65).
- (2) Install reel bolt and tighten to 37 N·m (27 ft.lbs.).
- (3) Route seat/shoulder belt through upper C pillar trim.
- (4) Install removed trim.
- (5) Install seat/shoulder belt turning loop.
- (6) Install lower seat/shoulder belt attaching bolt and tighten to 37 N·m (27ft.lbs.).
- (7) Move rear seat to upright position.

**REAR SEAT BELT BUCKLE**

The rear seat belt buckle is integral with the seat frame and not serviced as a separate part.


**FLOOR CONSOLE**

**CAUTION:** The ACM should be depowered by disconnecting the negative battery cable in any operation requiring the key to be turned "ON", while working in the console area. E.G. console, carpet, or seat removal or installation; shifter linkage adjustment or replacement; parking brake cable replacement or adjustment. Failure to take proper precautions could result in accidental airbag deployment and possible personal injury.

**REMOVAL**

- (1) Set park brake.
- (2) Place transmission shift lever and transfer case lever in full rearward position.

## REMOVAL AND INSTALLATION (Continued)




REAR SEAT/SHOULDER BELT

80bceab9

**Fig. 64 Rear Seat/Shoulder Belt**

- 1 - LOWER BELT BOLT  
2 - TURNING LOOP COVER

- 3 - TURNING LOOP BOLT  
4 - REEL BOLT



80bdbce6

**Fig. 65 Rear Seat/Shoulder Belt Reel Locator**

- 1 - SEAT/SHOULDER BELT REEL  
2 - INDEX TAB  
INDEX SLOT

- (3) Remove mat from front bin and remove screws attaching front of console to floor (Fig. 66).  
(4) Remove screws attaching rear bin to console.  
(5) Remove rear bin.

(6) Pull rear passenger cupholder outward to access screws.

(7) Remove screws attaching rear of console to floor.

(8) Lift the console upward and rearward.

(9) Remove console from vehicle.

**INSTALLATION**

(1) Position console in vehicle. Ensure rear passenger HEVAC duct is engaged.

(2) Install screws attaching rear of console to floor.

(3) Position rear bin in console.

(4) Install screws attaching rear bin to console.

(5) Install screws attaching front of console to floor and place front bin mat in front bin.

(6) Return transmission shift lever and transfer case lever to original position.


(7) Release park brake.

**FRONT CARPET****REMOVAL**

- (1) Remove door sill trim and lower "B" pillar trim.  
(2) Remove front seats and lower cushions of rear seats.  
(3) Remove center floor console.



REMOVAL AND INSTALLATION (Continued)



80b46cd1

**Fig. 66 Floor Console**

- |                     |                   |
|---------------------|-------------------|
| 1 - REAR BIN        | 5 - PARKING BRAKE |
| 2 - CONSOLE LID     | 6 - FRONT BIN     |
| 3 - SHIFTER CONSOLE | 7 - MAT           |
| 4 - BRACKET         |                   |

- (4) Remove any other interfering trim or molding.
- (5) Lift carpet and mat from floor panel.

**INSTALLATION**

- (1) Clean the floor panel area as necessary.
- (2) Carefully lay the carpet and mat on the floor panel. Align the carpet to allow installation of the components fastened to the floor panel.
- (3) Install the center console.
- (4) Install the front and rear seat units.
- (5) Install the lower "B" pillar trim and the door sill trim.
- (6) Install any other moldings or trim panels removed.

**CARGO AREA CARPET**

**REMOVAL**


- (1) Lift tailgate.
- (2) Fold rear seat cushions forward.
- (3) Remove rear seat backs, shoulder belts and buckles.
- (4) Remove the retractable security cargo cover assembly.

- (5) Remove the spare tire cover.
- (6) Remove the rear cargo tie down footman loops. The side mounted footman loops are retained by screws. The floor footman loops are riveted (Fig. 67).
- (7) Remove the "C" pillar trim and CD changer, if equipped.
- (8) Remove the Infinity amp, if equipped.
- (9) Lift the carpet.

**INSTALLATION**

- (1) Thoroughly clean the area with Mopar Super Kleen, or equivalent.
- (2) Lay the new carpet in.
- (3) Install the "C" pillar trim and CD changer, if equipped.
- (4) Install the footman loops.
- (5) Install the seat backs, shoulder belts and buckles.
- (6) Install the Infinity amp, if equipped.
- (7) Install the spare tire cover.
- (8) Install the retractable security cover.


## REMOVAL AND INSTALLATION (Continued)

**Fig. 67 Cargo Area Carpet**

- 1 - CARGO AREA CARPET  
2 - RIVET  
3 - CARGO TIE-DOWN LOOP

**REARVIEW MIRROR****REMOVAL**

- (1) If equipped, disconnect mirror harness connector.
- (2) Loosen the mirror base setscrew (Fig. 68).
- (3) Slide the mirror base upward and off the bracket.

**Fig. 68 Rearview Mirror**

- 1 - CONNECTOR  
2 - SCREW  
3 - ELECTROCHROMATIC REAR VIEW MIRROR  
4 - SUPPORT BUTTON  
5 - WINDSHIELD

**INSTALLATION**

- (1) Position the mirror base at the bracket and slide it downward onto the support bracket.
- (2) Tighten the setscrew 1 N·m (15 in. lbs.) torque.
- (3) If equipped, connect mirror harness connector.

**REARVIEW MIRROR SUPPORT BRACKET****INSTALLATION**

- (1) Mark the position for the mirror bracket on the outside of the windshield glass with a wax pencil.
- (2) Clean the bracket contact area on the glass. Use a mild powdered cleanser on a cloth saturated with isopropyl (rubbing) alcohol. Finally, clean the glass with a paper towel dampened with alcohol.
- (3) Sand the surface on the support bracket with fine grit-sandpaper. Wipe the bracket surface clean with a paper towel.
- (4) Apply accelerator to the surface on the bracket according to the following instructions:
  - Crush the vial to saturate the felt applicator.
  - Remove the paper sleeve.
  - Apply accelerator to the contact surface on the bracket.
  - Allow the accelerator to dry for five minutes.
  - Do not touch the bracket contact surface after the accelerator has been applied.
- (5) Apply adhesive accelerator to the bracket contact surface on the windshield glass. Allow the accelerator to dry for one minute. Do not touch the glass contact surface after the accelerator has been applied.
- (6) Install the bracket according to the following instructions:
  - Apply one drop of adhesive at the center of the bracket contact-surface on the windshield glass.
  - Apply an even coat of adhesive to the contact surface on the bracket.
  - Align the bracket with the marked position on the windshield glass.
  - Press and hold the bracket in place for at least one minute.

**NOTE:** Verify that the mirror support bracket is correctly aligned, because the adhesive will cure rapidly.

- (7) Allow the adhesive to cure for 8-10 minutes. Remove any excess adhesive with an alcohol-dampened cloth.

- (8) Allow the adhesive to cure for an additional 8-10 minutes before installing the mirror.

**SUNVISOR****REMOVAL**

- (1) Remove screws attaching sunvisor arm support bracket to headliner and roof panel.
- (2) Disengage electrical connections for vanity mirror, if equipped.
- (3) Detach sunvisor from support bracket.
- (4) Remove sunvisor from vehicle.

REMOVAL AND INSTALLATION (Continued)

- (5) Remove retaining screw and support bracket.

**INSTALLATION**

- (1) Install the retaining screw and support bracket.
- (2) Position the sunvisor in the vehicle.
- (3) Connect the electrical harness for the lighted vanity mirror, if equipped.
- (4) Attach the sunvisor to the support bracket.
- (5) Install the support bracket w/sunvisor onto the headliner and roof panel.

**HEADLINER**


**REMOVAL**

**CAUTION:** The headliner is a one-piece, molded component. It has limited flexibility and must not be bent. Damage may possibly result.

- (1) Record radio presets and disconnect negative battery cable.
- (2) Remove "A", "B", "C", and "D" pillar trim moldings.
- (3) Remove the sun visors. Disconnect vanity lamp wiring.
- (4) Remove assist handles from roof rails.
- (5) Remove dome lamp and overhead console, if equipped.
- (6) Remove rear cargo/dome lamp.
- (7) Remove sun roof pinch welt, if equipped.
- (8) Disengage rear washer hose from liftgate (Fig. 69).
- (9) Disengage the wire harness connectors at rear of headliner.
- (10) Disconnect the rear washer hose at the left "A" pillar (Fig. 70).
- (11) Disengage the wire harness for the sunroof, if equipped.
- (12) Fold down the rear seats, move the front seats full forward, and lower the front seat backs.
- (13) Partially lower the headliner and disengage the sunroof drain hoses, if equipped (Fig. 71).
- (14) With the aid of an assistant, remove the headliner through the liftgate opening.

**INSTALLATION**


- (1) With the aid of an assistant, position the headliner in the vehicle.
- (2) Connect the sunroof drain hoses, if equipped.
- (3) Connect the sunroof harness, the rear wire harnesses, and the washer hose at the "A" pillar and at the liftgate.
- (4) Install the sunroof pinch welt, if equipped.
- (5) Install the roof rail assist handles.
- (6) Install the sun visors and overhead console.
- (7) Install the rear cargo/dome lamp.



80b9a4cf

**Fig. 69 Liftgate Washer Hose Routing at Rear of Headliner**

- 1 - ROOF
- 2 - REAR WASHER HOSE ROUTING
- 3 - REAR WASHER HOSE
- 4 - HEADLINER




80b9a4d0

**Fig. 70 Rear Liftgate Washer Hose Routing at A Pillar**

- 1 - OVERHEAD CONSOLE WIRE HARNESS
- 2 - ROOF
- 3 - REAR WASHER HOSE
- 4 - REAR WASHER HOSE ROUTING
- 5 - HEADLINER

## REMOVAL AND INSTALLATION (Continued)

**Fig. 71 Headliner**

- 1 - SUNROOF PINCH WELT
- 2 - ROOF
- 3 - REAR WASHER HOSE

- 4 - HEADLINER
- 5 - SUNROOF

80b9a4ce

- (8) Install the "A", "B", "C", and "D" pillar trim.
- (9) Connect the negative battery cable.

**LIFTGATE TRIM PANEL**

**NOTE:** The liftgate trim panel is attached with screws and spring clips.

**REMOVAL**

- (1) Remove the screws securing the liftgate trim panel to the liftgate (Fig. 72).
- (2) Disconnect the rear window defroster wires.
- (3) Using a trim stick, or other suitable tool, pry the liftgate trim panel off the liftgate.

**INSTALLATION**

- (1) Align the liftgate trim panel spring clips and press the panel into the liftgate.
- (2) Install the trim panel screws.
- (3) Connect the rear defroster wires.

**LOWER LIFTGATE OPENING TRIM PANEL****REMOVAL**

- (1) Remove screws at outboard end of lower liftgate trim panel.
- (2) Open the spare tire cover and remove the screws near the center of the lower liftgate trim panel (Fig. 73).
- (3) Remove the lower liftgate trim panel.


**INSTALLATION**

- (1) Align the screw holes and locators to the holes in the liftgate opening.
- (2) Install the screws in the liftgate opening trim panel.
- (3) Install the spare tire cover.

**LIFTGATE INSULATOR****REMOVAL**

- (1) Remove the liftgate trim panel.
- (2) Separate the liftgate insulator from the liftgate and trim panel (Fig. 74).


REMOVAL AND INSTALLATION (Continued)



**Fig. 72 Liftgate Trim Panel**

- 1 - LIFTGATE
- 2 - LIFTGATE TRIM PANEL

80ba7980



**Fig. 74 Liftgate Insulator Pad**

- 1 - LIFTGATE
- 2 - INSULATION PAD

**INSTALLATION**

- (1) Thoroughly clean the area of any adhesive or insulation material.
- (2) Install the insulator in the liftgate.
- (3) Install the liftgate trim panel.
- (4) Close the liftgate and check the operation of the liftgate latch and rear wiper/washer, if equipped.

**LIFTGATE**


**REMOVAL**

**CAUTION: DO NOT DISCONNECT THE SUPPORT ROD CYLINDERS WITH THE LIFTGATE CLOSED. THE SUPPORT ROD PISTONS ARE OPERATED BY HIGH PRESSURE GAS. THIS PRESSURE COULD CAUSE DAMAGE AND /OR PERSONAL INJURY IF THEY ARE REMOVED WHILE THE PISTONS ARE COMPRESSED.**

- (1) Open the liftgate. Support the liftgate for ease of repair.
- (2) Remove the liftgate trim panel.
- (3) Remove the prop rods from the liftgate.
- (4) Unplug the wire harnesses and disconnect the washer hose.
- (5) Mark the hinge location with a wax pencil or other suitable device (Fig. 75).
- (6) Remove the hinge screws and remove liftgate from vehicle.

**INSTALLATION**

- (1) Position the liftgate on the vehicle and align the witness marks.
- (2) Install the hinge screws at liftgate. Tighten hinge screws to 28N·m (21ft. lbs.).




**Fig. 73 Liftgate Opening Trim Panel**

- 1 - UPPER LIFTGATE OPENING TRIM PANEL
- 2 - LOWER LIFTGATE OPENING TRIM PANEL

80ba7979

## REMOVAL AND INSTALLATION (Continued)

**Fig. 75 Liftgate**

- 1 - HINGE  
2 - LIFTGATE

(3) Connect the wire harnesses and the washer hose.

(4) Install the trim panel.

(5) Install the prop rods.

(6) Close the liftgate and check for proper latching and alignment.

**LIFTGATE HINGE**

**NOTE:** It is not necessary to remove the liftgate to replace one or both hinges. The hinges can be replaced one at a time.

**REMOVAL**

(1) Open the liftgate. Support the liftgate for ease of repair.

(2) Remove the liftgate header trim panel.

(3) Mark the hinge location with a grease pencil or other suitable device.

(4) Remove the hinge screws (Fig. 75).

(5) Remove hinge.

**INSTALLATION**

(1) Position the hinge on the roof panel and on the liftgate. (Use 3M™ Fast and Firm or equivalent on the hinge to body mating surfaces as a sealant.)

(2) Install and tighten hinge screws at roof panel to 28N·m (21 ft. lbs.).

(3) Install hinge screws at liftgate. Tighten screws to 28N·m (21 ft. lbs.).

(4) Install liftgate header trim panel.

(5) Check the liftgate for proper alignment and operation.

**LIFTGATE OUTSIDE HANDLE****REMOVAL**

(1) Raise the liftgate.

(2) Remove the liftgate trim panel (Refer to liftgate trim panel removal and installation in the Body section of this manual).

(3) Remove the latch, outside handle linkage, and power lock connector.

(4) Remove the fasteners attaching the outside handle to the liftgate.

(5) Remove the outside handle from the liftgate.

**INSTALLATION**

(1) Position the outside handle on the liftgate.

(2) Install the fasteners attaching outside handle to liftgate.

(3) Connect outside handle link and power lock connector.

(4) Install liftgate trim panel.

**LIFTGATE LATCH****REMOVAL**

(1) Raise the liftgate.

(2) Remove the liftgate trim panel (Fig. 76).

(3) Disconnect the power connector.

(4) Disconnect the outside handle link from the latch.

(5) Remove the latch screws and remove latch.

**INSTALLATION**

(1) Install the latch into the liftgate and tighten the screws to 7N·m (5 ft. lbs.).

(2) Connect the outside handle to the liftgate latch.

(3) Plug in the connector for the power.

(4) Install the liftgate trim panel.

**LIFTGATE LATCH STRIKER****REMOVAL**

(1) Raise liftgate.

(2) Remove tail lamp.

(3) Remove nuts attaching striker to D-pillar (Fig. 77).

(4) Separate striker from D-pillar.


**INSTALLATION**

(1) Position striker on D-pillar.

(2) Install nuts attaching striker to D-pillar. Tighten nuts to 10 N·m (7 ft. lbs.) torque.

(3) Install tail lamp.


REMOVAL AND INSTALLATION (Continued)



80b34e98

**Fig. 76**

- |               |                                 |
|---------------|---------------------------------|
| 1 - LATCH     | 5 - CLIP                        |
| 2 - LIFTGATE  | 6 - OUTSIDE HANDLE TO LATCH ROD |
| 3 - CONNECTOR | 7 - OUTSIDE HANDLE              |
| 4 - ACTUATOR  |                                 |



80b3c70e

**Fig. 77 Liftgate Latch Striker**

- |              |
|--------------|
| 1 - D-PILLAR |
| 2 - STRIKER  |

**LIFTGATE OPENING WEATHERSTRIP**


**REMOVAL**

- (1) Pull seal away from flange around edge of liftgate opening.
- (2) Separate weatherstrip from opening (Fig. 78).
- (3) Clean weatherstrip flange as necessary.

**INSTALLATION**

- (1) Position weatherstrip in opening with left end of seal at opening centerline.
- (2) Press weatherstrip onto flange in a clockwise direction.
- (3) Center and butt weatherstrip ends together at centerline.
- (4) If necessary, cut surplus from weatherstrip (non-plug end only).

## REMOVAL AND INSTALLATION (Continued)



**Fig. 78 Liftgate Opening Weatherstrip**

- 1 - LIFTGATE  
2 - WEATHERSTRIP

## FLIP UP GLASS

### REMOVAL

**CAUTION: DO NOT DISCONNECT THE PROP ROD CYLINDERS WITH THE LIFTGATE FLIP UP GLASS CLOSED. THE PROP ROD PISTONS ARE OPERATED BY HIGH PRESSURE GAS. THIS PRESSURE COULD CAUSE DAMAGE AND/OR PERSONAL INJURY IF THEY ARE REMOVED WHILE THE PISTONS ARE COMPRESSED.**

- (1) Using a trim stick or other suitable device, separate the flip up glass hinge cover from the hinge on the liftgate (Fig. 79).
- (2) Open liftgate flip up glass. Support the glass for ease of repair.
- (3) Using a small flat blade or equivalent tool, gently pry open the locking caps on the end of the prop rods.
- (4) Remove prop rod cylinders from ball studs.
- (5) Lower the flip up glass.
- (6) Remove hinge fasteners from liftgate.
- (7) Separate flip up glass from liftgate.

### INSTALLATION

- (1) Position flip up glass on liftgate.
- (2) Install hinge fasteners, hand tight only.
- (3) With the glass panel in the fully open position, fully raised position, push the glass forward to completely seat the hinges. Tighten hinge fasteners to 6N·m (60 in. lbs.).
- (4) Install prop rods on ball studs and compress locking caps to lock rods on ball studs.
- (5) Lower the flip up glass and install the flip up glass hinge cover.

- (6) Check the flip up glass for proper alignment and latching.

## FLIP UP GLASS WEATHERSTRIP

### REMOVAL

- (1) Raise flip up glass.
- (2) Carefully pull the seal away from the flange around the edge of the glass opening (Fig. 80).
- (3) Remove it from the vehicle.

### INSTALLATION

- (1) Thoroughly clean the surface of the flange as necessary.
- (2) Align the weather strip seal with the window opening corners.
- (3) Firmly seat the seal around the entire flange. But the seal ends together and smooth out any remaining length.
- (4) Weatherstrip break should be 120mm left of latch opening. Cut any surplus from non-plug end only.

## FLIP UP GLASS SWITCH

### REMOVAL

- (1) Remove license plate lamp housing/trim panel from liftgate.
- (2) Squeeze the locking tabs inward to release the switch from the housing.
- (3) Disconnect the switch harness connector, remove the switch from the housing.

### INSTALLATION

- (1) Install switch harness connector.
- (2) Position switch in housing, snap switch into place.
- (3) Install license plate lamp housing/trim panel onto liftgate.

## FLIP UP GLASS LATCH

### REMOVAL


- (1) Open liftgate flip up glass.
- (2) Open liftgate and remove trim panel (Fig. 81).
- (3) Remove latch.
- (4) Disconnect switch connectors.
- (5) Remove latch from liftgate.

### INSTALLATION

- (1) Position the latch on the liftgate.
- (2) Connect switch connectors.
- (3) Adjust latch to the proper position, and tighten the fasteners to 11 N·m (100 in. lbs.).
- (4) Close flip up glass panel and verify proper operation.




REMOVAL AND INSTALLATION (Continued)




**Fig. 79 Flip-Up Glass**

- |                   |            |
|-------------------|------------|
| 1 - FLIP-UP GLASS | 4 - BUMPER |
| 2 - HINGE COVER   | 5 - BUMPER |
| 3 - SUPPORT PROP  |            |



**Fig. 80 Flip-up Glass Weatherstrip**

- |                              |
|------------------------------|
| 1 - WEATHERSTRIP             |
| 2 - LIFTGATE W/FLIP-UP GLASS |



**Fig. 81 Flip-up Glass Latch**

- |              |
|--------------|
| 1 - LATCH    |
| 2 - LIFTGATE |

(5) Install liftgate trim panel.

## REMOVAL AND INSTALLATION (Continued)

## FLIP UP GLASS LATCH STRIKER

## REMOVAL

- (1) Raise flip up glass panel.
- (2) Mark the position of the handle/striker on the glass panel.
- (3) Remove the screws attaching the handle/striker to the glass.


## INSTALLATION

- (1) Position the handle/striker on the glass panel and align the reference marks.
- (2) Install the screws attaching the handle/striker to the glass panel. Tighten the fasteners to 6 N·m (60 in. lbs.).

## LICENSE PLATE LAMP HOUSING

## REMOVAL

- (1) Remove the screws retaining the lamp housing/trim panel to the liftgate (Fig. 82).
- (2) Disconnect the wire harness for the license plate lamps and the flip up glass switch, if equipped.
- (3) Remove the license plate lamps and the flip up glass switch, if equipped.
- (4) Remove the license plate lamp housing.



80b46b65

Fig. 82 License Plate Lamp Housing

- 1 - LICENSE PLATE LAMP
- 2 - CONNECTOR
- 3 - LIFTGATE


## INSTALLATION

- (1) Install the license plate lamps, and the flip up glass switch, if equipped.
- (2) Connect the wire harnesses for the license plate lamps and the flip up glass switch.
- (3) Install the lamp housing/trim panel on the liftgate.

## D-PILLAR APPLIQUE

## REMOVAL

- (1) Using a trim stick, carefully pry applique from panel (Fig. 83).



80b46ae0

Fig. 83 D-Pillar Applique &amp; Air Exhauster

- 1 - D-PILLAR EXHAUSTER
- 2 - D-PILLAR APPLIQUE
- 3 - CLIP
- 4 - TAIL LAMP EXHAUSTER

## INSTALLATION

- (1) Position applique on panel with retainers aligned.
- (2) Press applique firmly in place.

## D-PILLAR AIR EXHAUSTER

## REMOVAL

- (1) Remove D-pillar applique.
- (2) Carefully pry air exhauster from D-pillar using a flat blade screwdriver (Fig. 83).

## INSTALLATION

- (1) Reseal air exhauster using foam tape.
- (2) Install air exhauster on D-pillar.
- (3) Install D-pillar applique.

## TAIL LAMP AIR EXHAUSTER

## REMOVAL

- (1) Remove tail lamp.
- (2) Using a trim stick, pry the top of the air exhauster downward to detach the retaining clips.
- (3) Separate air exhauster from vehicle (Fig. 83).

## INSTALLATION

- (1) Position air exhauster in opening.
- (2) Press air exhauster inward to secure.

REMOVAL AND INSTALLATION (Continued)

- (3) Install tail lamp.

**LUGGAGE RACK**

**REMOVAL**

**NOTE: The skid strips are attached to the roof panel with adhesive.**

- (1) Using a trim stick, or other suitable device, pry support cover off.
- (2) If necessary, slide the crossbars to expose the screws attaching the slide rails to the supports.
- (3) Remove the screws retaining the slide rails to the supports.
- (4) Remove the screws attaching the supports to the roof panel.
- (5) Separate the supports from the roof panel.

**NOTE: If a crossbar needs to be serviced, the forward or rearward supports will have to be removed.**

**INSTALLATION**

- (1) Position the supports on the roof panel and install the screw. Be sure that the gasket is properly seated.
- (2) Position the luggage rack on the supports.
- (3) Install the screws attaching the side rails to the supports.
- (4) Position the supports covers on the supports and press into place.

**ADJUSTMENTS**

**HOOD ADJUSTMENT**

The hood attaching holes are enlarged to aid front, back and side to side adjustment.

- (1) If hood is low in relation to cowl panel, insert shims between hinge and hood.
- (2) Adjust hood bumper in or out to adjust hood-to-fender height alignment.
- (3) Adjust the hood latch as necessary. Tighten the nuts to 11N·m (8 ft. lbs.).
- (4) Align the latch striker so that striker enters the latch squarely and without binding.

**DOOR ADJUSTMENT**

Minor adjustment for alignment of the door is made by moving the latch striker.

**IN AND OUT**

- (1) Loosen the latch striker.
- (2) Tap the latch striker inward if the door character line is outboard of the body character line or tap the latch striker outward if the door character line is inboard of the body character line.

- (3) Inspect the alignment. If correct, tighten striker to 28 N·m (21 ft. lbs.).


**UP AND DOWN**

- (1) Loosen the latch striker.
- (2) Tap the latch striker downward if the door character line is higher than the body character line or tap the latch striker upward if the door character line is lower than the body character line.
- (3) Inspect the alignment. If correct, tighten to 28 N·m (21 ft. lbs.).

**DOOR LATCH**

**DOOR LATCH ADJUSTMENT**

- (1) Locate access hole (Fig. 84).
- (2) Insert a 5/32-inch hex-wrench through hole and into adjustment screw. Loosen screw.
- (3) Operate outside handle button several times to release any restriction because of mis-alignment.
- (4) Tighten adjustment screw to 3 N·m (30 in-lbs) torque.
- (5) Test handle button and lock cylinder for proper operation.



**Fig. 84 Door Latch Adjustment**

- 1 - ACCESS HOLE
- 2 - DOOR
- 3 - LATCH MOUNTING BOLTS
- 4 - LATCH

**LIFTGATE ADJUSTMENT**

The position of the liftgate can be adjusted upward or downward by the use of slots in the hinge. An inward or outward adjustment is achieved by use of slots in the body. If an inward or outward adjustment is needed, use 3M<sup>®</sup> Fast and Firm or equivalent on the hinge to body mating surface as a sealant.

## SPECIFICATIONS

## BODY LUBRICANTS


COMPONENT	SERVICE INTERVAL	LUBRICANT
Door Hinges	As Required	Multi-Purpose Grease NLGI GC-LB (Water Resistant) (1)
Door Latches	As Required	Multi-Purpose Grease NLGI GC-LB (Water Resistant) (1)
Hood Latch, Release Mechanism and Safety Latch	As Required (When Performing Other Underhood Service)	Multi-Purpose Grease NLGI GC-LB 2 EP (2)
Hood Hinges	As Required	Engine Oil
Seat Track and Release Mechanism	As Required	Multi-Purpose Grease NLGI GC-LB 2 EP (2)
Liftgate Hinge	As Required	Multi-Purpose Grease NLGI GC-LB 2 EP (2)
Liftgate Support Arms	As Required	Engine Oil
Liftgate Latches	As Required	White Spray Lubricant (3)
Liftgate Release Handle (Pivot and Slide Contact Surfaces)	As Required	Multi-Purpose Grease NLGI GC-LB 2 EP (2)
Window System Components	As Required	White Spray Lubricant (3)
Lock Cylinders	Twice a Year	Lock-Cylinder Lubricant (4)
Parking Brake Mechanism	As Required	Multi-Purpose Grease NLGI GC-LB 2 EP (1)
1 = Mopar Wheel Bearing Grease (High Temp) 2 = Mopar Multi-Mileage Lubricant 3 = Mopar Spray White Lube 4 = Mopar Lock Cylinder Lubricant		

SPECIFICATIONS (Continued)

WELD LOCATIONS

RADIATOR SUPPORT BRACKETS


W2 - WELDING OF 2 PARTS  
W3 - WELDING OF 3 PARTS  
W4 - WELDING OF 4 PARTS



80b6fe8a

SPECIFICATIONS (Continued)


FRONT SUSPENSION SUPPORT REINFORCEMENT



**W2 - WELDING OF 2 PARTS**  
**W3 - WELDING OF 3 PARTS**  
**W4 - WELDING OF 4 PARTS**

80b6fe8b



FRONT LOWER CROSSMEMBER TO COWL SIDE PANEL



80b6fe8c

SPECIFICATIONS (Continued)

FRONT SILL TO LOWER CROSSMEMBER




W2 - WELDING OF 2 PARTS  
W3 - WELDING OF 3 PARTS  
W4 - WELDING OF 4 PARTS

SPECIFICATIONS (Continued)

FRONT FENDER MOUNTING BRACKET AND REINFORCEMENT


W2 - WELDING OF 2 PARTS  
W3 - WELDING OF 3 PARTS  
W4 - WELDING OF 4 PARTS





SPECIFICATIONS (Continued)


FRONT SUSPENSION SUPPORT TO SILLS AND COWL SIDE PANEL



**W2 - WELDING OF 2 PARTS**  
**W3 - WELDING OF 3 PARTS**  
**W4 - WELDING OF 4 PARTS**


SPECIFICATIONS (Continued)

LEFT INSTRUMENT PANEL BRACKET TO COWL  
SIDE PANEL



SPECIFICATIONS (Continued)

COWL SIDE UPPER REINFORCEMENT TO COWL SIDE AND FRONT SUSPENSION SUPPORT




**W2 - WELDING OF 2 PARTS**  
**W3 - WELDING OF 3 PARTS**  
**W4 - WELDING OF 4 PARTS**

SPECIFICATIONS (Continued)

COWL SIDE PANEL TO DASH PANEL AND INNER BODYSIDE PANEL AND SILL


W2 - WELDING OF 2 PARTS  
W3 - WELDING OF 3 PARTS  
W4 - WELDING OF 4 PARTS



80b6feb3

PLENUM ASSEMBLY TO COWL SIDE PANEL

W2  
(RIGHT SIDE ONLY)




W2 - WELDING OF 2 PARTS  
W3 - WELDING OF 3 PARTS  
W4 - WELDING OF 4 PARTS

80b6fe5c

SPECIFICATIONS (Continued)

FRONT LOWER CROSSMEMBER




W2 - WELDING OF 2 PARTS
W3 - WELDING OF 3 PARTS
W4 - WELDING OF 4 PARTS

SPECIFICATIONS (Continued)


FRONT SUSPENSION SUPPORT TO DASH

W2 - WELDING OF 2 PARTS  
W3 - WELDING OF 3 PARTS  
W4 - WELDING OF 4 PARTS

RIGHT SIDE ONLY




LEFT SIDE ONLY



SPECIFICATIONS (Continued)

WIPER MOUNTING BRACKETS TO PLENUM ASSEMBLY




W2 - WELDING OF 2 PARTS  
W3 - WELDING OF 3 PARTS  
W4 - WELDING OF 4 PARTS

80b6fe3c

COWL TOP AND PLENUM ASSEMBLY


W2 - WELDING OF 2 PARTS  
W3 - WELDING OF 3 PARTS  
W4 - WELDING OF 4 PARTS



80b6fe3e

SPECIFICATIONS (Continued)


LOWER PLENUM REINFORCEMENT TO LOWER PLENUM PANEL



W2 - WELDING OF 2 PARTS  
W3 - WELDING OF 3 PARTS  
W4 - WELDING OF 4 PARTS

80b6fe3f

DASH PANEL TO LOWER PLENUM PANEL




W2 - WELDING OF 2 PARTS  
W3 - WELDING OF 3 PARTS  
W4 - WELDING OF 4 PARTS

80b6fe40




SPECIFICATIONS (Continued)

PLENUM ASSEMBLY TO COWL



80b6fe41


COWL PANEL TO BODYSIDE SILL



80b6fe42

SPECIFICATIONS (Continued)


COWL PANEL TO FRONT FLOOR PAN



**W2 - WELDING OF 2 PARTS**  
**W3 - WELDING OF 3 PARTS**  
**W4 - WELDING OF 4 PARTS**


SPECIFICATIONS (Continued)

FRONT SILLS TO DASH AND FRONT FLOOR PAN




SPECIFICATIONS (Continued)

COWL SIDE PANEL DASH INNER BODYSIDE AND OUTER BODYSIDE PANELS




W2 - WELDING OF 2 PARTS  
W3 - WELDING OF 3 PARTS  
W4 - WELDING OF 4 PARTS




SPECIFICATIONS (Continued)

UPPER FRONT INNER PILLAR TO ROOF AND COWL





SPECIFICATIONS (Continued)

DOOR OPENINGS



SPECIFICATIONS (Continued)


B-PILLAR REINFORCEMENT TO INNER BODYSIDE APERTURE



W2 - WELDING OF 2 PARTS  
W3 - WELDING OF 3 PARTS  
W4 - WELDING OF 4 PARTS


SPECIFICATIONS (Continued)

REAR QUARTER WINDOW TO BODYSIDE APERTURE INNER AND OUTER



80b6fe93

LOWER REAR QUARTER TO BODYSIDE APERTURE INNER AND OUTER






80b6fe94



SPECIFICATIONS (Continued)

INNER TRACK BAR, LOWER CONTROL ARM AND TRANSMISSION CROSSMEMBER BRACKETS TO FRONT SILLS





W2 - WELDING OF 2 PARTS  
W3 - WELDING OF 3 PARTS  
W4 - WELDING OF 4 PARTS

SPECIFICATIONS (Continued)



TRANSMISSION CROSSMEMBER BRACKET AND REINFORCEMENT TO FRONT SILLS

W2 - WELDING OF 2 PARTS  
W3 - WELDING OF 3 PARTS  
W4 - WELDING OF 4 PARTS



SPECIFICATIONS (Continued)


UPPER SILLS AND UPPER CONTROL ARM REINFORCEMENT AND BRACKETS TO FRONT SILLS



SPECIFICATIONS (Continued)

REINFORCEMENT TO FRONT OUTER SILLS


W2 - WELDING OF 2 PARTS  
W3 - WELDING OF 3 PARTS  
W4 - WELDING OF 4 PARTS



80b6fe85

FRONT INNER SILL TO FRONT OUTER SILL

W2 - WELDING OF 2 PARTS  
W3 - WELDING OF 3 PARTS  
W4 - WELDING OF 4 PARTS




80b6fe86

SPECIFICATIONS (Continued)


OUTER TRACK BAR BRACKET TO FRONT OUTER SILL

W2 - WELDING OF 2 PARTS  
W3 - WELDING OF 3 PARTS  
W4 - WELDING OF 4 PARTS



SPECIFICATIONS (Continued)

REINFORCEMENT FOR FRONT ENGINE MOUNTING AND STEERING GEAR TO FRONT INNER SILL




W2 - WELDING OF 2 PARTS  
W3 - WELDING OF 3 PARTS  
W4 - WELDING OF 4 PARTS

SPECIFICATIONS (Continued)



LARGE AND SMALL SWAY BAR TAPPING PLATES  
TO FRONT INNER SILLS

**W2 - WELDING OF 2 PARTS**  
**W3 - WELDING OF 3 PARTS**  
**W4 - WELDING OF 4 PARTS**



SPECIFICATIONS (Continued)

FRONT AND REAR DOOR HINGE TAPPING PLATES




**W2 - WELDING OF 2 PARTS**  
**W3 - WELDING OF 3 PARTS**  
**W4 - WELDING OF 4 PARTS**



SPECIFICATIONS (Continued)



REAR DOOR STRIKER REINFORCEMENT



**W2 - WELDING OF 2 PARTS**  
**W3 - WELDING OF 3 PARTS**  
**W4 - WELDING OF 4 PARTS**

SPECIFICATIONS (Continued)


TAIL LAMP MOUNTING PANELS



W2 - WELDING OF 2 PARTS  
W3 - WELDING OF 3 PARTS  
W4 - WELDING OF 4 PARTS

SPECIFICATIONS (Continued)


ROOF PANEL TO BODYSIDE APERTURE



W2 - WELDING OF 2 PARTS
W3 - WELDING OF 3 PARTS
W4 - WELDING OF 4 PARTS

SPECIFICATIONS (Continued)


ROOF PANEL TO REAR HEADER



W2 - WELDING OF 2 PARTS  
W3 - WELDING OF 3 PARTS  
W4 - WELDING OF 4 PARTS

SPECIFICATIONS (Continued)


UPPER REAR HEADER TO LOWER HEADER



W2 - WELDING OF 2 PARTS  
W3 - WELDING OF 3 PARTS  
W4 - WELDING OF 4 PARTS


SPECIFICATIONS (Continued)

FRONT HEADER AND ROOF BOWS TO INNER  
PANEL




SPECIFICATIONS (Continued)

FRONT SEAT/SHOULDER BELT TO INNER PANEL REINFORCEMENT




SPECIFICATIONS (Continued)

REAR SEAT/SHOULDER BELT TO INNER PANEL REINFORCEMENT



80b6fe4e

FUEL FILLER GUSSET TO INNER QUARTER PANEL




80b6fe4f




SPECIFICATIONS (Continued)

FRONT FLOOR PAN TO SILL REINFORCEMENT



SPECIFICATIONS (Continued)


CENTER FLOOR PAN TO REAR SEAT CROSSMEMBER



W2 - WELDING OF 2 PARTS  
W3 - WELDING OF 3 PARTS  
W4 - WELDING OF 4 PARTS

SPECIFICATIONS (Continued)


FRONT FLOOR PAN TO FRONT SEAT REINFORCEMENT AND RAILS



W2 - WELDING OF 2 PARTS  
W3 - WELDING OF 3 PARTS  
W4 - WELDING OF 4 PARTS


SPECIFICATIONS (Continued)

CENTER FLOOR PAN TO UPPER CONTROL ARM CROSSMEMBER AND RAILS



SPECIFICATIONS (Continued)


REAR FLOOR PAN TO RAILS AND SPRING GUIDE CROSSMEMBER



W2 - WELDING OF 2 PARTS  
W3 - WELDING OF 3 PARTS  
W4 - WELDING OF 4 PARTS


SPECIFICATIONS (Continued)

REAR RAILS



80b6fe32


UPPER CONTROL ARM CROSSMEMBER TO REAR RAIL



80b6fe33


SPECIFICATIONS (Continued)

REAR RAIL REINFORCEMENT TO REAR RAILS



SPECIFICATIONS (Continued)

UPPER CONTROL ARM REINFORCEMENTS TO REAR RAIL




W2 - WELDING OF 2 PARTS  
W3 - WELDING OF 3 PARTS  
W4 - WELDING OF 4 PARTS



SPECIFICATIONS (Continued)


OUTER TRANSMISSION CROSSMEMBER REINFORCEMENT TO RAIL AND BODYSIDE SILL



W2 - WELDING OF 2 PARTS  
W3 - WELDING OF 3 PARTS  
W4 - WELDING OF 4 PARTS

80b6fe36

BODYSIDE SILL TO FLOOR PAN




W2 - WELDING OF 2 PARTS  
W3 - WELDING OF 3 PARTS  
W4 - WELDING OF 4 PARTS

80b6fe37

SPECIFICATIONS (Continued)


REAR RAILS TO REAR CROSSMEMBER



W2 - WELDING OF 2 PARTS  
W3 - WELDING OF 3 PARTS  
W4 - WELDING OF 4 PARTS

80b6fe38

INNER WHEELHOUSE TO FLOOR PAN




W2 - WELDING OF 2 PARTS  
W3 - WELDING OF 3 PARTS  
W4 - WELDING OF 4 PARTS

80b6fe39

SPECIFICATIONS (Continued)

INNER WHEELHOUSE TO INNER BODYSIDE APERTURE AND FLOOR PAN


W2 - WELDING OF 2 PARTS  
W3 - WELDING OF 3 PARTS  
W4 - WELDING OF 4 PARTS



80b6feb4

OUTER WHEELHOUSE TO OUTER BODYSIDE APERTURE

W2 - WELDING OF 2 PARTS  
W3 - WELDING OF 3 PARTS  
W4 - WELDING OF 4 PARTS




80b6feb5

SPECIFICATIONS (Continued)


OUTER WHEELHOUSE TO INNER BODYSIDE APERTURE

W2 - WELDING OF 2 PARTS  
W3 - WELDING OF 3 PARTS  
W4 - WELDING OF 4 PARTS



80b6feb6

INNER BODYSIDE APERTURE TO OUTER BODYSIDE APERTURE




W2 - WELDING OF 2 PARTS  
W3 - WELDING OF 3 PARTS  
W4 - WELDING OF 4 PARTS

80b6feb7

SPECIFICATIONS (Continued)


REAR INBOARD SEAT BELT REINFORCEMENT TO FLOOR PAN




SPECIFICATIONS (Continued)

SEALER LOCATIONS


APPLICATION METHODS




HOLD GUN NOZZLE IN DIRECTION OF ARROW IN ORDER TO EFFECTIVELY SEAL METAL JOINTS.




DO NOT HOLD GUN NOZZLE IN DIRECTION OF ARROW. SEALER APPLIED AS SHOWN IN INEFFECTIVE.




3 METAL THICKNESS



2 METAL THICKNESS




3 METAL THICKNESS



2 METAL THICKNESS

EXPOSED SURFACE →  
WORK SEAL ON METAL SURFACE TO GET GOOD ADHESIVE. EDGE MUST BE FEATHERED AS SHOWN.



SEALER MUST BE APPLIED AS ILLUSTRATED. TO LOCK SEAL IN PLACE, FORCE SEAL BEYOND HOLE.

HIDDEN SURFACE

EXPOSED SURFACE




HIDDEN SURFACE

SEALER INCORRECTLY APPLIED

SYMBOLS	
	THUMBGRADEABLE SEALER
	EXTRUDABLE THERMOPLASTIC
	EXPOSED THERMOPLASTIC SEALANT
	HIDDEN SEALANT

SPECIFICATIONS (Continued)



COWL PLENUM AND DASH PANEL



80b6e1a

SPECIFICATIONS (Continued)



DASH, COWL AND PLENUM






SPECIFICATIONS (Continued)

INNER FENDER AND COWL



SPECIFICATIONS (Continued)


LOWER PLENUM AND BAFFLE



APPLY TO PLENUM LOWER REAR FLANGE  
AND PLENUM BAFFLE FLANGE.

80b6fe1b



A-PILLAR



80b6fe29


SPECIFICATIONS (Continued)

COWL SIDE ATTACHMENT




SPECIFICATIONS (Continued)

BODYSIDE ATTACHMENT



**THUMBGRADE ROPE  
150 MM X 9 MM BALL  
(TYPICAL BOTH SIDES)**

**APPLY TO BODYSIDE ASSEMBLY  
PRIOR TO SPRAY SEALER  
APPLICATION**




**SPRAYABLE ADHESIVE  
(TYPICAL BOTH SIDES)**

**APPLY AFTER MIG WELDS BUT  
PRIOR TO FENDER INSTALLATION**


SPECIFICATIONS (Continued)

BODYSIDE INNER AND OUTER TO COWL




SPECIFICATIONS (Continued)

FENDER ATTACHMENT




**45 MM X 30 MM X 1.25 MM PATCH  
(TYPICAL BOTH SIDES)**

**APPLY ON TOP OF FENDER  
ATTACHING SLOTS PRIOR TO  
ATTACHING FENDER BRACKETS**





SPECIFICATIONS (Continued)

DOOR HINGE BOLT HOLES



SPECIFICATIONS (Continued)



A-PILLAR AND B-PILLAR HINGE AREA







SPECIFICATIONS (Continued)

B-PILLAR AND SILL




SPECIFICATIONS (Continued)

SILL AND B-PILLAR




SPECIFICATIONS (Continued)

**BODYSIDE APERTURE AND REAR WHEELHOUSE**



80b6fe21


**FUEL FILLER GUSSET**




80b6fe24

SPECIFICATIONS (Continued)

OUTER WHEELHOUSE FLANGE




LIFTGATE OPENING



SPECIFICATIONS (Continued)


**INNER WHEELHOUSE FLANGE TO BODYSIDE APERTURE**



**PUMPABLE SEALER  
1100 MM X 6 MM BEAD  
ALONG ENTIRE WHEELHOUSE  
FLANGES ON APERTURE INNER**

80b6fe56

**WHEELHOUSE LOWER**





**THUMBGRADE SEALER  
20 MM BALL**

**THUMBGRADE SEALER  
30 MM BALL  
(TYPICAL BOTH SIDES)  
TO OUTER FRONT CORNER  
OF WHEELHOUSE INNER**

80b6fe57

SPECIFICATIONS (Continued)

REAR INNER CROSSMEMBER




SECTION B - B


☉ OF SEALER BEAD  
TO BE APPROXIMATELY 8 MM  
REARWARD OF FRONT EDGE  
OF REAR INNER CROSSMEMBER

SPECIFICATIONS (Continued)

ROOF TO BODY SIDE APERTURE



PUMPABLE SEALER  
2200 MM X 3 MM BEAD




SECTION A-A  
(TYPICAL BOTH SIDES)

80b6fe25

STRUCTURAL ADHESIVE LOCATIONS


COWL PLENUM



80b6fe97

SPECIFICATIONS (Continued)

DASH PANEL AND FRONT FLOOR PAN




8066e98




SPECIFICATIONS (Continued)

PLENUM AND WINDSHIELD WIPER MOUNTING

**DRAINAGE FLUTES**




**SPRAYABLE ADHESIVE  
900 MM X 25 MM X 2 MM  
APPLY ON TOP OF SPOT WELDS.  
AVOID ALL DRAINAGE FLUTES.**



**SPRAYABLE ADHESIVE  
200 MM X 25 MM X 2 MM  
APPLY ON TOP OF SPOT WELDS  
(LEFT SIDE ONLY)**


SPECIFICATIONS (Continued)

FRONT FLOOR PAN AND SILLS



80b6fe99


FRONT AND CENTER FLOOR PAN



80b6fe9a


SPECIFICATIONS (Continued)

FRONT PAN AND INNER BODY SIDE APERTURE




SPECIFICATIONS (Continued)

REAR SEAT CROSSMEMBER



80b6fe9b


REAR INNER WHEELHOUSE



80b6fe9c



SPECIFICATIONS (Continued)

FLOOR PAN AND SILL ASSEMBLY




SPECIFICATIONS (Continued)

FLOOR PAN




SPECIFICATIONS (Continued)

REAR INNER WHEELHOUSE AND REAR FLOOR PAN



80b6fe9f


RIGHT INNER BODYSIDE APERTURE



80b6fe23


SPECIFICATIONS (Continued)

BODY SIDE INNER PANEL AND WHEELHOUSE



80b6fea0

BODY SIDE OUTER PANEL AND REAR WHEELHOUSE OUTER PANEL




80b6fea1



SPECIFICATIONS (Continued)



D-PILLAR AND FUEL FILLER GUSSETS



80b6fea2


SPECIFICATIONS (Continued)

LIFTGATE



SPECIFICATIONS (Continued)


TAILLAMP MOUNTING PANEL




80b6fea3

SPECIFICATIONS (Continued)

TAILLAMP




**STRUCTURAL ADHESIVE  
800 MM X 6 MM BEAD  
AROUND COMPLETE FLANGES  
OF TAIL LAMP FLANGES**



**STRUCTURAL ADHESIVE  
350 MM X 3 MM BEAD  
BETWEEN TAIL LAMP AND  
LIFTGATE TROUGH FLANGE**


SPECIFICATIONS (Continued)

REAR INNER CROSSMEMBER



80b6faa4


ROOF BOWS



80b6fe95

SPECIFICATIONS (Continued)


REAR LOWER HEADER



SPECIFICATIONS (Continued)

**BODY GAP AND FLUSH MEASUREMENTS**

**WJ FRONT VIEW**




	LOCATION	GAP	FLUSH
A	Front Door to Windshield Pillar	N/A	3.0 +/- 1.0
B	Front Door Header to Aperture	6.0 +/- 1.0	1.0 +/- 1.5
C	Front Door to Rear Door	5.0 +/- 1.0	0.0 +/- 1.0
D	Front Door to Aperture at Sill	7.0 +/- 1.5	N/A
E	Front Door to Fender	5.0 +/- 1.0	0.5 +/- 1.0
F	Hood to Fender	5.0 +/- 1.0	0.0 +/- 1.0
G	Headlamp to Fender	5.0 +/- 2.0	3.0 +/- 2.0
H	Headlamp to Grille	5.5 +/- 2.0	0.0 +/- 2.0
I	Grille to Headlamp	N/A	0.0 +/- 1.0
J	Grille to Hood	10.0 +/- 2.0	0.8 +/- 2.0
K	Front Fascia to Fender	Net + 1.0 - 0.0	3.0 +/- 3.0
L	Fuel Filler Door to Bodyside	3.0 +/- 0.75	0.5 +/- 0.75

**NOTE: ALL MEASUREMENTS ARE IN MM.**

## SPECIFICATIONS (Continued)

## WJ REAR VIEW




	LOCATION	GAP	FLUSH
M	Rear Door to Quarter Panel	5.0 +/- 1.0	0.0 +/- 1.0
N	Aperture to Rear Fascia	Net to 1.0	3.0 +/- 2.0
O	Taillamp to Quarter Panel	2.0 +/- 1.0	3.0 +/- 1.5
P	Taillamp to Liftgate	5.0 +/- 1.5	3.0 +/- 1.5
Q	Liftgate to Fascia	10.0 +/- 3.0	N/A
R	Liftgate to Aperture	5.0 +/- 1.5	1.0 +/- 1.0
S	Liftgate to Roof	11.0 +/- 1.5	1.0 +/- 1.0
T	Rear Door Header to Aperture	6.0 +/- 1.0	1.0 +/- 1.5

**NOTE:** ALL MEASUREMENTS ARE IN MM.




SPECIFICATIONS (Continued)

**BODY OPENING DIMENSIONS  
WINDSHIELD AND FRONT DOOR OPENING**




**ALL MEASUREMENTS IN MILLIMETERS**




- A. & B.** Center of radius at bottom to center of radius at top.
- C.** Center of front door lower rear corner radius to center of A-pillar radius.
- D.** Center of door hinge mount to center of door striker mount.
- E.** Center of radius at bottom front to center of radius at top rear.
- F.** Center of radius at bottom rear to center of radius at lower A-pillar.

## SPECIFICATIONS (Continued)

## REAR DOOR AND QUARTER GLASS OPENING



- A. Quarter panel to front outer body side upper and lower seam.
- B. Center of front upper door radius to center of rear lower door radius.
- C. Center of front lower door radius to center of rear upper door radius.
- D. Rear door hinge mount to rear door striker mount.





- A. Center of upper and lower rear quarter window opening.
- B. Center of radius front lower corner to center of radius rear upper corner.
- C. Center of radius front upper corner to center of radius rear lower corner.

**ALL MEASUREMENTS IN MILLIMETERS**

SPECIFICATIONS (Continued)

LIFTGATE OPENING AND ENGINE COMPARTMENT



ALL MEASUREMENTS IN MILLIMETERS

SPECIFICATIONS (Continued)


TORQUE SPECIFICATIONS

BODY COMPONENTS

<b>DESCRIPTION</b>	<b>TORQUE</b>
Sunroof module to roof panel. . . . .	11N·m (97 in. lbs.).
Front bucket seat to floor pan bolts. . . . .	40N·m (30 ft. lbs.).
Front bucket seat to floor pan front bolts. . . . .	40N·m (30 ft. lbs.).
Bucket seat track adjuster nuts to seat cushion frame. . . . .	28N·m (20 ft. lbs.).
Bucket seat recliner to seat back frame bolts. . . . .	28N·m (20 ft. lbs.).
Bucket seat back frame recliner bolts to seat cushion frame. . . . .	28N·m (20 ft. lbs.).
Rear seat cushion latch base panel screws. . . . .	8 N·m (75 in. lbs.).
Rear seat cushion to floor pan bolts. . . . .	11 N·m (8 ft. lbs.).
Rear seat back left side support bracket to center pivot bracket. . . . .	28 N·m (20 ft. lbs.).
Rear seat back right side support bracket. . . . .	28N·m (20 ft. lbs.).
Rear seat back latch/hinge to seat back frame. . . . .	28N·m (20 ft.lbs.).
Hood latch to radiator crossmember. . . . .	11N·m (8 ft.lbs.).
Front door hinge bolts. . . . .	35N·m (26 ft. lbs.).
Front door latch to door screws. . . . .	10N·m (7 ft. lbs.).
Front door striker to B pillar. . . . .	28N·m (20 ft. lbs.).
Rear door latch to door screws. . . . .	10N·m (95 in. lbs.).
Rear door striker to C pillar screws. . . . .	28N·m (250 in. lbs.).
Rear view mirror set screw. . . . .	1N·m (15 in. lbs.).
Lift gate latch striker to D pillar nuts. . . . .	10N·m (7 ft. lbs.).
Door latch adjustment screw. . . . .	3N·m (30 in. lbs.).

SPECIAL TOOLS

BODY



**Remover, Moldings C-4829**